



CTRIO High-Speed Counter Module

Manual Number: HX-CTRIO-M

WARNING

Thank you for purchasing automation equipment from Automationdirect.com™. We want your new automation equipment to operate safely. Anyone who installs or uses this equipment should read this publication (and any other relevant publications) before installing or operating the equipment.

To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and usually change with time. It is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation is in compliance with the latest revision of these codes.

At a minimum, you should follow all applicable sections of the National Fire Code, National Electrical Code, and the codes of the National Electrical Manufacturer's Association (NEMA). There may be local regulatory or government offices that can also help determine which codes and standards are necessary for safe installation and operation.

Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

Our products are not fault-tolerant and are not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the product could lead directly to death, personal injury, or severe physical or environmental damage ("High Risk Activities").

Automationdirect.com™ specifically disclaims any expressed or implied warranty of fitness for High Risk Activities.

For additional warranty and safety information, see the Terms and Conditions section of our catalog. If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call us at 770-844-4200.

This publication is based on information that was available at the time it was printed. At Automationdirect.com™ we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without any obligation. This publication may also discuss features that may not be available in certain revisions of the product.

Trademarks

This publication may contain references to products produced and/or offered by other companies. The product and company names may be trademarked and are the sole property of their respective owners. Automationdirect.com™ disclaims any proprietary interest in the marks and names of others.

**Copyright 2003, Automationdirect.com™ Incorporated
All Rights Reserved**

No part of this manual shall be copied, reproduced, or transmitted in any way without the prior, written consent of Automationdirect.com™ Incorporated. Automationdirect.com™ retains the exclusive rights to all information included in this document.

⚡ AVERTISSEMENT ⚡

Nous vous remercions d'avoir acheté l'équipement d'automatisation de Automationdirect.comMC. Nous tenons à ce que votre nouvel équipement d'automatisation fonctionne en toute sécurité. Toute personne qui installe ou utilise cet équipement doit lire la présente publication (et toutes les autres publications pertinentes) avant de l'installer ou de l'utiliser.

Afin de réduire au minimum le risque d'éventuels problèmes de sécurité, vous devez respecter tous les codes locaux et nationaux applicables régissant l'installation et le fonctionnement de votre équipement. Ces codes diffèrent d'une région à l'autre et, habituellement, évoluent au fil du temps. Il vous incombe de déterminer les codes à respecter et de vous assurer que l'équipement, l'installation et le fonctionnement sont conformes aux exigences de la version la plus récente de ces codes.

Vous devez, à tout le moins, respecter toutes les sections applicables du Code national de prévention des incendies, du Code national de l'électricité et des codes de la National Electrical Manufacturer's Association (NEMA). Des organismes de réglementation ou des services gouvernementaux locaux peuvent également vous aider à déterminer les codes ainsi que les normes à respecter pour assurer une installation et un fonctionnement sûrs.

L'omission de respecter la totalité des codes et des normes applicables peut entraîner des dommages à l'équipement ou causer de graves blessures au personnel. Nous ne garantissons pas que les produits décrits dans cette publication conviennent à votre application particulière et nous n'assumons aucune responsabilité à l'égard de la conception, de l'installation ou du fonctionnement de votre produit.

Nos produits ne sont pas insensibles aux défaillances et ne sont ni conçus ni fabriqués pour l'utilisation ou la revente en tant qu'équipement de commande en ligne dans des environnements dangereux nécessitant une sécurité absolue, par exemple, l'exploitation d'installations nucléaires, les systèmes de navigation aérienne ou de communication, le contrôle de la circulation aérienne, les équipements de survie ou les systèmes d'armes, pour lesquels la défaillance du produit peut provoquer la mort, des blessures corporelles ou de graves dommages matériels ou environnementaux («activités à risque élevé»). La société Automationdirect.comMC nie toute garantie expresse ou implicite d'aptitude à l'emploi en ce qui a trait aux activités à risque élevé.

Pour des renseignements additionnels touchant la garantie et la sécurité, veuillez consulter la section Modalités et conditions de notre documentation. Si vous avez des questions au sujet de l'installation ou du fonctionnement de cet équipement, ou encore si vous avez besoin de renseignements supplémentaires, n'hésitez pas à nous téléphoner au 770-844-4200.

Cette publication s'appuie sur l'information qui était disponible au moment de l'impression. À la société Automationdirect.com, nous nous efforçons constamment d'améliorer nos produits et services. C'est pourquoi nous nous réservons le droit d'apporter des modifications aux produits ou aux publications en tout temps, sans préavis ni quelque obligation que ce soit. La présente publication peut aussi porter sur des caractéristiques susceptibles de ne pas être offertes dans certaines versions révisées du produit.

Marques de commerce

La présente publication peut contenir des références à des produits fabriqués ou offerts par d'autres entreprises. Les désignations des produits et des entreprises peuvent être des marques de commerce et appartiennent exclusivement à leurs propriétaires respectifs. Automationdirect.comMC nie tout intérêt dans les autres marques et désignations.

Copyright 2003, Automationdirect.com™ Incorporated
Tous droits réservés

Nulle partie de ce manuel ne doit être copiée, reproduite ou transmise de quelque façon que ce soit sans le consentement préalable écrit de la société Automationdirect.com™ Incorporated. Automationdirect.com™ conserve les droits exclusifs à l'égard de tous les renseignements contenus dans le présent document.

MANUAL REVISIONS



Please include the Manual Number and the Manual Issue, both shown below, when communicating with Technical Support regarding this publication.

Manual Number: HX-CTRIO-M
Issue: Second Edition, Rev. B
Issue Date: 10/03

Publication History		
Issue	Date	Description of Changes
First Edition	9/01	Original
Rev. A	10/01	Corrections
Rev. B	8/02	Corrections
Second Edition	2/03	Added T1H-CTRIO and H4-CTRIO. Updated for CTRIO/Workbench version 2.
Rev. A	10/03	Added H0-CTRIO and flowcharts.
Rev. B	10/03	Corrections

TABLE OF CONTENTS



Chapter 1: Introduction to the CTRIO Modules

CTRIO Version 2 and Workbench Version 2 New Features	1-2
Expanded I/O Map Implications	1-2
Using CTRIO/Workbench Version 1	1-2
CTRIO Module Overview	1-3
CTRIO Workbench	1-3
CTRIO Functions	1-3
Typical Counter Applications:	1-4
Support Systems for the CTRIO Modules	1-4
H0-CTRIO	1-4
H2-CTRIO	1-4
H4-CTRIO	1-4
T1H-CTRIO	1-4
CTRIO Specifications	1-5
H0-CTRIO LED Indicators	1-7
H2-CTRIO LED Indicators	1-8
H4-CTRIO LED Indicators	1-9
T1H-CTRIO LED Indicators	1-10

Chapter 2: Installation and Field Wiring

Installing the H0-CTRIO Module	2-2
CPU and CTRIO Compatibility Chart	2-2
Sinking Outputs	2-3
Sourcing Outputs	2-3
Jumper Selections	2-3
Setting H0-CTRIO Jumpers	2-3

Wiring the H0-CTRIO Module	2-4
H0- CTRIO Quadrature Encoder Wiring Example	2-5
H0-CTRIO TTL Quadrature Encoder Field Wiring	2-6
H0-CTRIO TTL Input Wiring	2-7
Sinking Outputs Jumper Settings	2-8
Sourcing Outputs Jumper Settings	2-8
H0- CTRIO Output Wiring Schematic	2-8
Sinking Outputs Jumper Settings	2-9
H0-CTRIO Stepper/Servo Drive Wiring Example	2-9
Installing the H2-CTRIO Module	2-10
CPU and CTRIO Compatibility Chart	2-10
Setting H2-CTRIO Jumpers	2-11
Wiring the H2-CTRIO Module	2-12
H2- CTRIO Quadrature Encoder Wiring Example	2-13
H2-CTRIO TTL Quadrature Encoder Field Wiring	2-14
H2-CTRIO TTL Input Wiring	2-15
H2- CTRIO Output Wiring Schematic	2-16
H2-CTRIO Stepper/Servo Drive Wiring Example	2-17
Installing the H4-CTRIO	2-18
CPU and CTRIO Compatibility Chart	2-18
Wiring the H4-CTRIO Module	2-19
H4-CTRIO Quadrature Encoder Wiring Example	2-20
H4-CTRIO TTL Quadrature Encoder Field Wiring	2-21
H4-CTRIO TTL Input Wiring	2-22
H4-CTRIO Output Wiring Schematic	2-23
H4-CTRIO Stepper/Servo Drive Wiring Example	2-24
Installing the T1H-CTRIO	2-25
CPU and CTRIO Compatibility Chart	2-25
Wiring the T1H-CTRIO Module	2-26
T1H-CTRIO Output Field Wiring	2-27
T1H-CTRIO Input Field Wiring	2-27

T1H-CTRIO Quadrature Encoder Wiring Example	2-28
T1H-CTRIO TTL Quadrature Encoder Field Wiring	2-29
T1H-CTRIO TTL Input Wiring	2-30
T1H-CTRIO Output Wiring Schematic	2-31
T1H-CTRIO Stepper/Servo Drive Wiring Example	2-32
PNP Field Device	2-33
NPN Field Device	2-33
Solid State Input Device Wiring to H0/H2/H4/T1H-CTRIO	2-33

Chapter 3: Introduction to CTRIO Workbench

What is CTRIO Workbench?	3-2
Installing CTRIO Workbench	3-2
Getting Started with CTRIO Workbench	3-2
Offline CTRIO Configuration	3-2
Online CTRIO Configuration	3-3
Successful On-line Connection	3-4
Module Modes of Operation	3-5
Program Mode - Configuring the CTRIO Module	3-5
Run Mode - Start Processing I/O Pulses with the CTRIO Module	3-5

Chapter 4: Configuring the Inputs Using CTRIO Workbench

Configure IO Dialog Overview	4-2
Input Function Selections	4-3
Supported Functions	4-3
Discrete Outputs Pre-Assigned to Input Functions	4-3
Counter Function	4-4
Quad Counter	4-5
Pulse Catch	4-6
Edge Timer	4-7
Dual Edge Timer	4-8
Soft Resets	4-9
Reset 1 and Reset 2 (Hard Resets for Counters Only)	4-9

Capture 14-10

Inhibit 14-10

Introduction to the Scaling Wizard4-11

 Scaling Wizard Examples for Counter Functions4-11

 Position Scaling (Counter)4-12

 Rate Scaling (Counter)4-13

 Using the Scaling Wizard with Timer Functions4-14

 Interval Scaling (Timer)4-14

Chapter 5: Configuring the Outputs Using CTRIO Workbench

Configure IO Dialog Overview5-2

Output Function Selections5-3

 Supported Functions5-3

 CTRIO Memory Usage: Pulse Profiles and Preset Tables5-3

Raw Output5-4

Discrete Outputs5-5

 Creating and Using the Output Preset Tables5-6

 Using the Discrete Outputs in Level Mode5-7

Pulse Outputs5-8

 Creating Pulse Output Profile Tables5-8

Trapezoidal Profile5-9

S-Curve Profile5-10

Symmetrical S-Curve Profile5-11

Dynamic Positioning Profile5-12

Dynamic Velocity Profile5-13

Home Search Profile5-14

 Home Search Routines5-15

Additional Pulse Profiles5-16

Chapter 6: Program Control

Input (n) Parameter Definitions	6-2
Input Memory Map for Data Transfers from CTRIO to CPU	6-2
Output Status Bit Definitions (Pulse Output)	6-3
Output Status Bit Definitions (for Preset Table Control)	6-3
Input Function Status Bit Definitions	6-3
Output (n) Parameter Definitions	6-4
Output Memory Map for Data Transfers from CPU to CTRIO	6-4
Output (n) Parameter Definitions	6-5
Output Control Bit Definitions (Raw Mode)	6-5
Output Control Bit Definitions (for Preset Table Control)	6-5
Output Control Bit Definitions (Pulse Output)	6-5
Input Function Control Bit Definitions	6-5
System Functions Control Bit Definitions	6-6
System Functions Status Bit Definitions	6-6
I/O Map Dialog	6-7
I/O Map with <i>DirectLogic</i> PLC (2 ranges mode)	6-7
I/O Map with <i>DirectLogic</i> PLC (4 ranges mode)	6-8
I/O Map with EBC/WinPLC	6-9
I/O Map with <i>DirectLogic</i> PLC with CTRIO in ERM/EBC Network	6-9
I/O Map with an H2-PBC or T1H-PBC Profibus DP Controller	6-10
I/O Map with a T1K-DEVNETS DeviceNet Controller	6-11
I/O Map with a T1K-MODBUS Modbus RTU Controller	6-13
Exporting to <i>DirectSOFT</i>	6-14
Printing a Memory Map Report	6-14
Addressing Conventions	6-15
(with V-memory Examples for DirectLOGIC PLCs)	6-15
Example for Bit-accessed Data in PLC CPUs	6-15
Addressing High and Low Byte of Word Parameters	6-15
Addressing High and Low Word of DWord Parameters	6-15
Input Function Status DWord Parameters	6-16
Input Function Status Bit Definitions	6-16
Input Function Control Bit Definitions	6-16

Input Function Status/Control Bits and Parameters	6-16
Control Registers	6-17
Status Registers	6-17
Example Input Control/Status Bits and Parameter Register Addresses	6-17
Memory Mapping Example for D2-240 CPU	6-18
Input Functions	6-19
Counter & Quadrature Counter	6-19
Edge Timer and Dual Edge Timer	6-20
Edge and Dual Edge Timer Timeout Function	6-21
Pulse Catch Input Function	6-22
Runtime Changes to CTRIO Configured Preset Tables	6-23
Entry Number for Edit Table Entry Commands	6-24
Entry Type for Edit Table Entry Commands	6-24
Discrete Outputs Driven from a Scaled level	6-25
Load Preset Table Flowchart	6-26
Pulse Output Status/Control Bits and Command Codes	6-27
Command Code and Parameter Definitions	6-28
Status Bits	6-29
Control Bits/Registers	6-29
Memory Mapping Example for D2-240 CPU	6-30
Pulse Output Profiles	6-31
Trapezoid, S-Curve, Symmetrical S-Curve, Home Search Profiles	6-32
Trapezoid, S-Curve, Symmetrical S-Curve and Home Search Flowchart	6-33
Running a Trapezoid, S-Curve, Symmetrical S-Curve, or Home Search Profile ...	6-34
Dynamic Positioning	6-35
Dynamic Positioning Flowchart	6-36
Dynamic Positioning using the CTRIO Y0 and Y1	6-37
Dynamic Velocity using the CTRIO Y0 and Y1	6-38
Dynamic Velocity	6-38
Dynamic Velocity Mode Flowchart	6-39
Velocity Mode	6-40
Velocity Mode control on CTRIO Y0 & Y1	6-40
Velocity Mode Flowchart	6-41
Run to Limit Mode	6-42
Run to Limit Mode Flowchart	6-43

Run at Velocity on CTRIO Y0 & Y1 until Discrete Input Limit 6-44

Run to Position Mode 6-45

Run to Position Mode Flowchart 6-46

Run at Velocity on CTRIO until Input Function Value Position 6-47

System Functions 6-48

 Reading All CTRIO's Internal Registers Flowchart 6-49

 Writing to All CTRIO's Internal Registers Flowchart 6-50

 Writing to One CTRIO Internal Register Flowchart 6-51

Chapter 7: Using Monitor I/O

Using the Monitor I/O Dialog 7-2

 I/O Status & Input Functions 7-3

 Output Functions 7-4

 System Functions 7-6

Monitor I/O Error Codes 7-7

Chapter 8: DirectLogic Programming Examples

Programming Examples Overview 8-2

Load and Run a Pulse Profile 8-3

Dynamic Positioning 8-4

Dynamic Velocity 8-5

Velocity Mode 8-6

Run to Limit Mode 8-7

Run to Position Mode 8-8

System Functions Examples Overview 8-9

Simulating Retentive Counter 8-10

Reading CTRIO Internal Registers 8-11

INTRODUCTION TO THE CTRIO MODULE



In This Chapter...

CTRIO Version 2 and Workbench 2 New Features	1-2
CTRIO Module Overview	1-3
Support Systems for the CTRIO Module	1-4
CTRIO Specifications	1-5
H0-CTRIO LED Indicators	1-7
H2-CTRIO LED Indicators	1-8
H4-CTRIO LED Indicators	1-9
T1H-CTRIO LED Indicators	1-10

CTRIO Version 2 and Workbench Version 2 New Features

Below is a list of the new features that were added to H0/H2/H4/T1H-CTRIO and Workbench version 2. **Module firmware version 2 requires CTRIO Workbench version 2 for proper configuration.** Firmware versions and CTRIO Workbench can be downloaded from www.automationdirect.com.

CTRIO version 2 / Workbench version 2 new features:

1. added H0-CTRIO, H4-CTRIO and T1H-CTRIO support.
2. added 5 user configurable Home Search Profiles.
3. added I/O mapping details for all PLC/Controller interface modules.
4. status of CTRIO onboard outputs are now part of the I/O map.
5. added System Functions (to Monitor I/O and through I/O map) that allow you to read and write to the CTRIOs internal registers. Doing this **expanded the I/O map by 32 input bits and 32 output bits**. This gives you the ability to write a stored value into the current count register to simulate retentive counts memory. It also gives you the ability to read the current pulse count. You can also change the 'reset to' value without reconfiguring the CTRIO.
6. added Dynamic Velocity profile, similar to straight velocity but adds accel/decel between velocity changes and determines direction from the input velocity value.
7. added offline configuration options for all CPU/Controllers.
8. can configure the CTRIO outputs as Raw (simple discrete outputs).
9. added Timeout feature for Timer Functions and Suspend Output feature for pulse outputs.

Expanded I/O Map Implications

DL205 DirectLogic Users (Does not apply to DL05/405 and Terminator I/O Users)

If you have a H2-CTRIO configuration created in version 1 with the outputs mapped immediately following the inputs, you will need to adjust the V-memory assignments in your PLC program if you intend to use CTRIO/Workbench version 2.

For example, if your existing CTRIO map uses V2000-V2023 for inputs and V2024-V2053 for outputs, you will need to adjust the output V-memory starting address by 32 bits to make room for the additional input memory usage (V2000-V2025 for the inputs and V2026-V2057 for the outputs). Also, if you are presently using any of the four V-memory locations immediately following the output memory map (V2053-V2057), those V-memory locations will also be adjusted due to the expanded I/O memory usage.

H2-PBC Users

The H2-PBC requires an updated .GSD file for use with Workbench version 2. This can be downloaded from www.automationdirect.com.

H2-WinPLC, H2/H4-EBC, T1K-DEVNETS, T1K-MODBUS and T1H-PBC Users

These controllers are not impacted by the expanded I/O map in version 2.

Using CTRIO/Workbench Version 1

If you prefer to continue using CTRIO version 1 and Workbench version 1, you will need to use the “update Firmware” function within Workbench to load version 1.0.1 firmware into the CTRIO module. Version 2 features will not be accessible when using version 1 firmware.

CTRIO Module Overview

The H0-CTRIO, H2-CTRIO, H4-CTRIO and T1H-CTRIO Counter I/O (CTRIO) modules are designed to accept high-speed pulse-type input signals for counting or timing applications and designed to provide high-speed pulse-type output signals for servo/stepper motor control, monitoring, alarm or other discrete control functions.

All CTRIO modules offer great flexibility for applications which call for precise counting or timing, based on input events or for high speed control output applications. The CTRIO can be used for applications that call for a combination of both high-speed input and high-speed output control functions.




For ease of documentation purposes, CTRIO will be used to designate all four CTRIO modules (H0-CTRIO, H2-CTRIO, H4-CTRIO and T1H-CTRIO) when the functionality and/or description applies to all four modules.

The CTRIO module has its own microprocessor and operates asynchronously with respect to the CPU. The response time of on-board outputs is based on the module's scan time, not the CPU's scan time.

CTRIO Workbench

All module configuration is done via a software utility, eliminating the need for ladder programming to configure the module. The software utility is called CTRIO Workbench.



CTRIO Functions

The CTRIO module supports five primary input functions: Counter, Quad Counter, Pulse Catch, Edge Timer, and Dual Edge Timer.

Three secondary input functions are also supported. These functions, Reset, Capture, and Inhibit, each modify the primary input functions in some way. Information is available about each of the primary and secondary functions in chapter 4.

The CTRIO module supports three primary output functions: Pulse train output for servo/stepper motor control, configurable for CW/CCW or step and direction, discrete output functions assigned to Counter/Timer input functions, and raw output control directly from the CPU interface program. Information is available about each of the output functions in chapter 5.

Typical Counter Applications:

- High-speed cut to length operations using encoder input
- Pick-and-place or indexing functions controlling a stepper drive
- Dynamic registration for web material control
- Accurate frequency counting for speed control with onboard scaling
- positioning (e.g. flying punch)
- PLS - programmable limit switch functions for packaging, gluing or labeling
- stepper motor drive control
- valve control
- rate monitoring for speed and/or flow

Support Systems for the CTRIO Modules

The CTRIO modules are compatible with several CPU-slot interfaces. Consideration must be given to the firmware versions of the CPU-slot interfaces to assure their compatibility with the CTRIO. (See Chapter 2 for CPU/CTRIO compatibility listings). Multiple CTRIO modules can reside in the same base provided that the backplane power budget is adequate.

Support Systems for the H0-CTRIO:

You can use the H0-CTRIO module in:

- *DirectLogic* 05/06 PLC systems

Support Systems for the H2-CTRIO:

You can use the H2-CTRIO module in:

- *DirectLogic* 205 PLC systems (D2-240, D2-250-1 or D2-260)
- DL205 WinPLC systems (H2-WPLCx-xx)
- PC-based control strategies using the H2-EBC interface module
- Hx-ERM networks using the H2-EBC interface module
- Profibus systems using the H2-PBC slave interface module

Support Systems for the H4-CTRIO:

You can use the H4-CTRIO module in:

- *DirectLogic* 405 PLC systems (D4-450 only)
- PC-based control strategies using the H4-EBC interface module
- Hx-ERM networks using the H4-EBC interface module

Support Systems for the T1H-CTRIO:

You can use the T1H-CTRIO module in:

- PC-based control strategies using the T1H-EBC interface module
- Profibus systems using the T1H-PBC slave interface module
- Hx-ERM networks using the T1H-EBC interface module
- Modbus systems using the T1K-MODBUS slave interface module
- DeviceNet systems using the T1K-DEVNETS slave interface module

CTRIO Specifications

General	
Module Type	Intelligent
Modules Per Base	Limited only by power consumption
I/O Points Used	None, I/O map directly in PLC V-memory or PC control access
Field Wiring Connector	Standard removable terminal block
Internal Power Consumption	400mA Max at +5V from Base Power Supply (H2, H4, T1H-CTRIO) 250mA at +5V from Base Power Supply (H0-CTRIO) (All I/O in ON State at Max Voltage/Current)
Operating Environment	32°F to 140°F (0°C to 60°C), Humidity (non-condensing) 5% to 95%
Manufacturer	Host Automation Products, LLC
Isolation	2500V I/O to Logic, 1000V among Input Channels and All Outputs

CTRIO Input Specifications	
Inputs (H2, H4, T1H-CTRIO)	8 pts. sink/source 100K Hz Max
Inputs (H0-CTRIO)	4 pts. sink/source 100K Hz Max
Minimum Pulse Width	5 μ sec
Input Voltage Range	9-30VDC
Maximum Voltage	30VDC
Input Voltage Protection	Zener Clamped at 33VDC
Rated Input Current	8mA typical 12mA maximum
Minimum ON Voltage	9.0VDC
Maximum OFF Voltage	2.0VDC
Minimum ON Current	5.0mA (9VDC required to guarantee ON state)
Maximum OFF Current	2.0mA
OFF to ON Response	Less than 3 μ sec
ON to OFF Response	Less than 3 μ sec

CTRIO Input Resources	
Counter/Timer (H2, H4, T1H-CTRIO)	4, (2 per each 4 input channel group); supports 2 quadrature counters max.
Counter/Timer (H0-CTRIO)	2, (2 per single 4 input channel); supports 1 quadrature counter max.
Resource Options	1X, 2X, or 4X Quadrature, Up or Down Counter, Edge Timer, Dual Edge Timer, Input Pulse Catch, Reset, Inhibit, Capture
Timer Range/ Resolution	\pm 4.2 billion (32 bits); 1 μ sec
Counter Range	\pm 2.1 billion (32 bits or 31 bits + sign bit)

CTRIO Specifications

CTRIO Output Specifications	
Outputs (H2, H4, T1H-CTRIO)	4 pts, independently isolated, current sourcing or sinking FET Outputs: open drain and source with floating gate drive
Outputs (H0-CTRIO)	2 pts, isolated, either both current sourcing or both current sourcing FET Outputs: open drain and source with floating gate drive
Voltage range	5VDC - 36VDC
Maximum voltage	36VDC
Output clamp voltage	60VDC
Maximum load current	1.0A
Maximum load voltage	36VDC
Maximum leakage current	100 μ A
Inrush current	5A for 20ms
OFF to ON response	less than 3 μ sec
ON to OFF response	less than 3 μ sec
ON state V drop	$\leq 0.3V$
External power supply	for loop power only, not required for internal module function*
Overcurrent protection	15A max
Thermal shutdown	T _{junction} = 150°C
Overtemperature reset	T _{junction} = 130°C
Duty cycle range	1% to 99% in 1% increments (default = 50%)
Configurable Presets a) single b) multiple	a) each output can be assigned one preset, or b) each output can be assigned one table of presets, one table can contain max. 128 presets, max. predefined tables = 255

* User supplied power source required for stepper drive configurations

CTRIO Output Resources	
Pulse output / Discrete outputs (H2, H4, T1H-CTRIO)	Pulse outputs: 2 channels (2 outputs per each channel) Discrete outputs: 4 pts.
Pulse output / Discrete outputs (H0-CTRIO)	Pulse outputs: 1 channel (2 outputs per single channel) Discrete outputs: 2 pts.
Resource Options	Pulse outputs: pulse/direction or cw/ccw; Profiles: Trapezoid, S-Curve, Symmetrical S-Curve, Dynamic Position, Dynamic Velocity, Home Search, Velocity Mode, Run to Limit Mode, Run to Position Mode Discrete outputs: configurable for set, reset, pulse on, pulse off, toggle, reset count functions (assigned to respond to Timer/Count input functions). Raw mode: Direct access to discrete outputs from user application program
Target Position Range	± 2.1 billion (32 bits or 31 bits + sign bit)

H0-CTRIO LED Indicators

H0-CTRIO LED Descriptions	
OK	Module OK
ERR	User Program Error
A	Ch1 F1 Resource State
B	Ch1 F2 Resource State
Y0 - Y1	Output Status



H0-CTRIO LED Diagnostic Definitions		
OK	ERR	Description
ON	OFF	All is well - RUN Mode
ON	ON	Hardware Failure
Blinking	Blinking	Boot Mode - Used for Field OS Upgrades
Blinking	OFF	Program Mode
OFF	Blinking	Module Self-diagnostic Failure
OFF	ON	Module Error Due to Watchdog Timeout
OFF	OFF	No Power to Module

H0-CTRIO LED Diagnostic Definitions	
A	Blinks when Channel 1 Function 1 is counting or timing
B	Blinks when Channel 1 Function 2 is counting or timing
Y0 - Y1	Follow actual output state; ON = output is passing current

H2-CTRIO LED Indicators

H2-CTRIO LED Descriptions	
OK	Module OK
ER	User Program Error
1A	Channel 1 Status
2A	Channel 2 Status
0 - 3	Output Status



H2-CTRIO LED Diagnostic Definitions		
OK	ER	Description
ON	OFF	All is well - RUN Mode
ON	ON	Hardware Failure
Blinking	Blinking	Boot Mode - Used for Field OS Upgrades
Blinking	OFF	Program Mode
OFF	Blinking	Module Self-diagnostic Failure
OFF	ON	Module Error Due to Watchdog Timeout
OFF	OFF	No Power to Module

H2-CTRIO LED Diagnostic Definitions	
1A /2A	
Blinking 7 times per second	Input is Configured as Counter and is Changing
Following State of Input	Input is not Configured as Counter
0 - 3	
Follow actual output state; ON = output is passing current	

H4-CTRIO LED Indicators

H4-CTRIO LED Descriptions	
OK	Module OK
ER	User Program Error
1A - 1D	Ch1A - Ch1D Input Status
2A - 2D	Ch2A - Ch2D Input Status
(Ch1) F1 - F2	Ch1 Resource State
(Ch2) F1 - F2	Ch2 Resource State
Y0 - Y3	Output Status



H4-CTRIO LED Diagnostic Definitions		
OK	ER	Description
ON	OFF	All is well - RUN Mode
Blinking	Blinking	Boot Mode - Used for Field OS Upgrades
Blinking	OFF	Program Mode
OFF	Blinking	Module Self-diagnostic Failure
OFF	ON	Module Error Due to Watchdog Timeout
OFF	OFF	No Power to Module
TB		User Terminal Block is not Properly Installed

H4-CTRIO LED Diagnostic Definition	
1A - 1D	Follow actual input state / Ch1
2A - 2D	Follow actual input state / Ch2
(Ch1) F1	blinks when Channel 1 Function 1 is counting or timing
(Ch1) F2	blinks when Channel 1 Function 2 is counting or timing
(Ch2) F1	blinks when Channel 2 Function 1 is counting or timing
(Ch2) F2	blinks when Channel 2 Function 2 is counting or timing
Y0 - Y3	Follow actual output state; ON = output is passing current



Due to the multiplexed design of the DL405 LED matrix, OFF state LEDs may appear to blink ON slightly. This is to be expected and does not necessarily indicate a transient condition of the function corresponding to the LED.

T1H-CTRIO LED Indicators

T1H-CTRIO LED Descriptions	
OK	Module OK
ER	User Program Error
CH1	Channel 1 Status
CH2	Channel 2 Status
1A - 1D	Channel 1 A-D Input Status
2A - 2D	Channel 2 A-D Input Status
Y0 - Y3	Output Status



T1H-CTRIO LED Diagnostic Definitions		
OK	ER	Description
ON	OFF	All is well - RUN Mode
ON	ON	Hardware Failure
Blinking	Blinking	Boot Mode - Used for Field OS Upgrades
Blinking	OFF	Program Mode
OFF	Blinking	Module Self-diagnostic Failure
OFF	ON	Module Error Due to Watchdog Timeout
OFF	OFF	No Power to Module

T1H-CTRIO LED Diagnostic Definitions	
CH1	Blinks when Channel 1 Function 1 is counting or timing
CH2	Blinks when Channel 2 Function 1 is counting or timing
Y0 - Y3	Follow actual output state; ON = output is passing current

INSTALLATION AND FIELD WIRING



In This Chapter...

Installing the H0-CTRIO Module	2-2
Setting the H0-CTRIO Jumpers	2-3
Wiring the H0-CTRIO Module	2-4
H0-CTRIO Quadrature Encoder Wiring Example	2-5
H0-CTRIO TTL Quadrature Encoder Wiring Example	2-6
H0-CTRIO TTL Input Wiring Example	2-7
H0-CTRIO Output Wiring Schematic	2-8
H0-CTRIO Stepper Drive Wiring Example	2-9
Installing the H2-CTRIO Module	2-10
Setting the H2-CTRIO Jumpers	2-11
Wiring the H2-CTRIO Module	2-12
H2-CTRIO Quadrature Encoder Wiring Example	2-13
H2-CTRIO TTL Quadrature Encoder Wiring Example	2-14
H2-CTRIO TTL Input Wiring Example	2-15
H2-CTRIO Output Wiring Schematic	2-16
H2-CTRIO Stepper Drive Wiring Example	2-17
Installing the H4-CTRIO Module	2-18
Wiring the H4-CTRIO Module	2-19
H4-CTRIO Quadrature Encoder Wiring Example	2-20
H4-CTRIO TTL Quadrature Encoder Wiring Example	2-21
H4-CTRIO TTL Input Wiring Example	2-22
H4-CTRIO Output Wiring Schematic	2-23
H4-CTRIO Stepper Drive Wiring Example	2-24
Installing the T1H-CTRIO Module	2-25
Wiring the T1H-CTRIO Module	2-26
T1H-CTRIO Quadrature Encoder Wiring Example	2-28
T1H-CTRIO TTL Quadrature Encoder Wiring Example	2-29
T1H-CTRIO TTL Input Wiring Example	2-30
T1H-CTRIO Output Wiring Schematic	2-31
T1H-CTRIO Stepper Drive Wiring Example	2-32
Solid State Input Device Wiring to H0/H2/H4/T1H-CTRIO	2-33

Installing the H0-CTRIO Module

The H0-CTRIO module is compatible with *DirectLogic* DL05 and DL06 PLCs. Consideration must be given to the firmware versions of the PLCs to assure their compatibility with the H0-CTRIO. (see chart below).

The H0-CTRIO module plugs into any option card slot of any DL05 and DL06 PLC.

For installation instructions, refer to the:

- DL05 or DL06 User Manual (D0-USER-M or D0-06USER-M)

The first time you power-up the CTRIO module, you should see the OK LED blinking. The blinking LED indicates that the module is in program mode.


CPU and CTRIO Compatibility Chart

PLC CPU	Firmware	<i>DirectSOFT32</i>
DL05	v. 4.60 or later	v. 4.0, Build 16 or later
DL06	v. 1.40 or later	v. 4.0, Build 16 or later

Updated firmware versions can be downloaded from our web site at www.automationdirect.com


Setting H0-CTRIO Jumpers

The module's internal jumpers must be set to the High Side Common position for high side switching (sourcing) outputs or to the Low Side Common position for low side switching (sinking) outputs. The sink/source jumper selection sets both outputs to the same option. Source operation is the factory default setting.




Jumper Selections

Sourcing Outputs



High Common position for switching the high side of a DC load.

Sinking Outputs



Low Common position for switching the low side of a DC load.

Wiring the H0-CTRIO Module

The H0-CTRIO module has one input channel, consisting of 4 optically isolated input points (pts. A-D on common M). The inputs can be wired to either sink or source current. The module has 2 optically isolated output points (pts. Y0-Y1 on common YC). The outputs can be wired to either sink or source current, but the sink/source jumper selection sets both outputs to the same option. Sourcing outputs must be wired so positive current flows into the YC terminal and then out of the Yn terminal. Sinking outputs must be wired so positive current flows into Yn terminal and then out of the YC terminal (see the diagram to the right and the schematic on page 2-8).

Source operation is the factory default setting for the outputs.

The module is configured, using CTRIO Workbench, to accommodate the user's application. The function of each input (counting, timing, reset, etc.) and output (pulse output, discrete output, etc.) is defined in the configuration of the module.

Refer to Chapters 4 and 5 to determine what input and output configurations are possible.




Field device wiring must be compatible with the module configuration.


See the notes below for further details about power source considerations, circuit polarities, and field devices. Also, refer to the specifications on pages 1-5 and 1-6 for more information.

Notes:


1. **Inputs (A, B, C, and D) require user-provided 9-30VDC power sources. Terminal M is the commons for the inputs. Maximum current consumption is 12mA per input point.**
2. **Polarity of the input power sources (shown above) can be reversed. Consideration must be given, however, to the polarity of the field device. Many field devices are designed for only one polarity and can be damaged if power wiring is reversed.**
3. **The maximum allowable current per output circuit is 1A.**




H0- CTRIO Quadrature Encoder Wiring Example



H0-CTRIO TTL Quadrature Encoder Field Wiring




H0-CTRIO TTL Input Wiring




H0- CTRIO Output Wiring Schematic


See page 2-3 for locating and setting the jumpers



H0-CTRIO Stepper/Servo Drive Wiring Example



Sinking Outputs Jumper Settings



See page 2-3 for locating and setting the jumpers

Installing the H2-CTRIO Module

The H2-CTRIO module is compatible with several DL205 CPU-slot interface devices. Consideration must be given to the firmware versions of the CPU-slot interfaces to assure their compatibility with the H2-CTRIO. (see chart below).

The H2-CTRIO module plugs into any I/O slot of any *DirectLogic* 205 base except slot 0 when using a *DirectLogic* PLC or H2-PBC controller. Slot 0 is available for the H2-CTRIO module when using the WinPLC or H2-EBC interface devices. (Slot 0 is the I/O slot adjacent to the CPU). The H2-CTRIO cannot be used in DL205 local expansion bases or in Serial Remote I/O bases.

For installation instructions, refer to the:

- DL205 User Manual (D2-USER-M) if using a *DirectLogic* PLC
- DL205 Installation and I/O Manual (D2-INST-M) if using a WinPLC, EBC, Profibus slave interface module

The first time you power-up the CTRIO module, you should see the OK LED blinking. The blinking LED indicates that the module is in program mode.

CPU and CTRIO Compatibility Chart


CPU-slot Device	Firmware	Hardware	<i>DirectSOFT32</i>	Slot Restrictions
D2-240	v. 3.22 or later	-	v. 3.0C, Build 71 or later	any I/O slot except 0
D2-250	v. 1.56 or later	-	v. 3.0C, Build 71 or later	any I/O slot except 0
D2-250-1	v. 3.5 or later	-	v. 3.0C, Build 71 or later	any I/O slot except 0
D2-260	v. 1.2 or later	-	v. 4.0 or later	any I/O slot except 0
H2-WinPLC	-	xK or later	-	any I/O slot
H2-EBC	v. 2.1.357 or later	-	-	prior to Rev 9A any I/O slot except 0; Rev 9A or later any I/O slot
H2-PBC	-	-	-	prior to Rev 4A any I/O slot except 0; Rev 4A or later any I/O slot

Updated firmware versions can be downloaded from our web site at www.automationdirect.com

Note: for applications requiring multiple CTRIO modules, *DirectLOGIC* CPUs, and dynamic access (in ladder logic) to CTRIO data, we recommend using the D2-250-1 or D2-260 CPU. These CPUs support Bit-of-Word addressing, 32 bit math instructions and have adequate memory for multiple CTRIO applications.

Setting H2-CTRIO Jumpers

Jumpers are provided to connect input commons or outputs/output commons. Use of these jumpers is not necessary to set up the CTRIO module. The jumpers are provided solely for convenience in wiring.



Jumper Settings	
1M to 2M	Share input commons between Ch 1 & Ch 2 Example: for High Side (sourcing) outputs on Y0-Y3, use the C0 to C1, C0 to C2, and C0 to C3 jumpers. Wire 5-36VDC to any of the C terminals. Example: for Low Side (sinking) outputs on C0-C3, use the Y0 to Y1, Y0 to Y2 and Y0 to Y3 jumpers. Wire 0VDC (GND) to any one of the Y terminals.
Y0 to Y1, Y2, Y3	Share commons between high or low side of outputs when isolation is not required
C0 to C1, C2, C3	

Wiring the H2-CTRIO Module



The H2-CTRIO module has two independent input channels, each consisting of 4 optically isolated input points (pts. 1A-1D on common 1M and pts. 2A-2D on common 2M). The inputs can be wired to either sink or source current.

The module has 4 optically isolated output points (pts. Y0-Y3 with isolated commons C0-C3, respectively). The outputs must be wired so positive current flows into Cn terminal and then out of the Yn terminal (see the diagram below and the schematic on page 2–16).

Remember that the internal jumpers can be used to connect the input commons or outputs/output commons together.

The module is configured, using CTRIO Workbench, to accommodate the user's application. The function of each input (counting, timing, reset, etc.) and output (pulse output, discrete output, etc.) is defined in the configuration of the module.

Refer to Chapters 4 and 5 to determine what input and output configurations are possible.




Field device wiring must be compatible with the module configuration.

See the notes below for further details about power source considerations, circuit polarities, and field devices. Also, refer to the specifications on pages 1-5 and 1-6 for more information.


Notes:

- Inputs (1A, 1B, 1C, 1D and 2A, 2B, 2C, 2D) require user-provided 9-30VDC power sources. Terminals 1M and 2M are the commons for Channel 1 and Channel 2 inputs. Maximum current consumption is 12mA per input point.**
- Polarity of the input power sources (shown above) can be reversed. Consideration must be given, however, to the polarity of the field device. Many field devices are designed for only one polarity and can be damaged if power wiring is reversed.**
- Outputs have one polarity only (as shown above) and are powered by user-provided 5-36VDC power sources. The maximum allowable current per output circuit is 1A.**

H2- CTRIO Quadrature Encoder Wiring Example




H2-CTRIO TTL Input Wiring




H2- CTRIO Output Wiring Schematic

The CTRIO outputs are individually isolated DC switches that can be used to break the high or the low side of a DC load.



H2-CTRIO Stepper/Servo Drive Wiring Example



This example assumes that the Step Amplifier interface to be optocoupler LEDs (common anodes at the “OPTO Power” terminal) with internal current limiting resistors. This is a standard method, but you must consult your step amplifier documentation to ensure that this method is applicable.

Installing the H4-CTRIO

The H4-CTRIO module is compatible with two DL405 CPU-slot interface devices. Consideration must be given to the firmware versions of the CPU-slot interfaces to assure their compatibility with the H4-CTRIO. (see chart below).

The H4-CTRIO module plugs into any I/O slot of any *DirectLogic* 405 base. H4-EBCs support the use of the H4-CTRIO in DL405 local expansion bases. The H4-CTRIO cannot be used in Serial Remote I/O bases.

For installation instructions, refer to the:

- DL405 User Manual (D4-USER-M) if using a *DirectLogic* PLC
- DL405 Installation and I/O Manual (D4-INST-M) if using an H4-EBC interface

The first time you power-up the CTRIO module, you should see the OK LED blinking. The blinking LED indicates that the module is in program mode.

CPU and CTRIO Compatibility Chart

CPU-slot Device	Firmware	Hardware	<i>DirectSOFT32</i>
D4-450	April 2000 or earlier: H8 (CISC) v. 2.00 SH (RISC) v. 1.500 May 2000 or later: H8 (CISC) v. 2.00 SH (RISC) v. 2.500	-	v. 4.0, Build 16 or later
H4-EBC	2.1.328 or later	v. 4F or later	-

Updated firmware versions can be downloaded from our web site at www.automationdirect.com

Wiring the H4-CTRIO Module

The H4-CTRIO module has two independent input channels, each consisting of 4 optically isolated input points (pts. 1A-1D on common 1M and pts. 2A-2D on common 2M). The inputs can be wired to either sink or source current.

The module has 4 optically isolated output points (pts. Y0-Y3 on isolated commons C0-C3, respectively). The outputs must be wired so that positive current flows into Cn terminal and then out of the Yn terminal (see the diagram below and the schematic on page 2-23).



The module is configured, using CTRIO Workbench, to accommodate the user's application. The function of each input (counting, timing, reset, etc.) and output (pulse output, discrete output, etc.) is defined in the configuration of the module.

Refer to Chapters 4 and 5 to determine what input and output configurations are possible.



Field device wiring must be compatible with the module configuration.


See the notes below for further details about power source considerations, circuit polarities, and field devices. Also, refer to the specifications on pages 1-5 and 1-6 for more information.




Notes:

- Inputs (1A, 1B, 1C, 1D and 2A, 2B, 2C, 2D) require user-provided 9-30VDC power sources. Terminals 1M and 2M are the commons for Channel 1 and Channel 2 inputs. Maximum current consumption is 12mA per input point.
- Polarity of the input power sources (shown above) can be reversed. Consideration must be given, however, to the polarity of the field device. Many field devices are designed for only one polarity and can be damaged if power wiring is reversed.
- Outputs have one polarity only (as shown above) and are powered by user-provided 5-36VDC power sources. The maximum allowable current per output circuit is 1A.


H4-CTRIO Quadrature Encoder Wiring Example



H4-CTRIO TTL Quadrature Encoder Field Wiring




H4-CTRIO TTL Input Wiring




H4-CTRIO Output Wiring Schematic

The CTRIO outputs are individually isolated DC switches that can be used to break the high or the low side of a DC load.



H4-CTRIO Stepper/Servo Drive Wiring Example



This example assumes that the Step Amplifier interface to be optocoupler LEDs (common anodes at the “OPTO Power” terminal) with internal current limiting resistors. This is a standard method, but you must consult you step amplifier documentation to ensure that this method is applicable.

Installing the T1H-CTRIO

The T1H-CTRIO module is compatible with several Terminator I/O Network interface devices. Consideration must be given to the firmware versions of the Network interfaces to assure their compatibility with the T1H-CTRIO. (see chart below).

The T1H-CTRIO module plugs into any valid I/O slot in a Terminator I/O system. The T1H-CTRIO cannot be used in Serial Remote I/O bases (T1K-RSSS).

For installation instructions, refer to the:

- Terminator I/O Installation and I/O Manual (T1K-INST-M)

The first time you power-up the CTRIO module, you should see the OK LED blinking. The blinking LED indicates that the module is in program mode.

CPU and CTRIO Compatibility Chart

CPU-slot Device*	Firmware	Hardware
T1H-EBC	v. 1.0.444 or later	v. 2I or later
T1H-PBC	v. 1.1.10 or later	v. 2D or later
T1K-DEVNETS	v. 1.80 or later	-
T1K-MODBUS	v. 1.80 or later	-

Updated firmware versions can be downloaded from our web site at www.automationdirect.com

Wiring the T1H-CTRIO Module

The T1H-CTRIO module has two independent input channels, each consisting of 4 optically isolated input points (pts. 1A-1D on common 1M and pts. 2A-2D on common 2M). The inputs can be wired to either sink or source current.

The module has 4 optically isolated output points (pts. Y0-Y3 on isolated commons C0-C3, respectively). The outputs must be wired so that positive current flows into Cn terminal and then out of the Yn terminal. (see the diagram on the following page and the schematic on page 2-31)

The module is configured, using CTRIO Workbench, to accommodate the user's application. The function of each input (counting, timing, reset, etc.) and output (pulse output, discrete output, etc.) is defined in the configuration of the module.



Refer to Chapters 4 and 5 to determine what input and output configurations are possible.



Field device wiring must be compatible with the module configuration.

See the notes below for further details about power source considerations, circuit polarities, and field devices. Also, refer to the specifications on pages 1-5 and 1-6 for more information.


Apply the labels that come with the I/O module to the I/O base terminals to properly identify the base terminal points.




Notes:

- Inputs (1A, 1B, 1C, 1D and 2A, 2B, 2C, 2D) require user-provided 9-30VDC power sources. Terminals 1M and 2M are the commons for Channel 1 and Channel 2 inputs. Maximum current consumption is 12mA per input point.
- Polarity of the input power sources can be reversed. Consideration must be given, however, to the polarity of the field device. Many field devices are designed for only one polarity and can be damaged if power wiring is reversed.
- Outputs have one polarity only and are powered by user-provided 5-36VDC power sources. The maximum allowable current per output circuit is 1A.
- User Bus 1 and User Bus 2 are each an independent 8 wiring terminal bus. They can be used for additional power rail connections.


T1H-CTRIO Input Field Wiring




T1H-CTRIO Output Field Wiring




T1H-CTRIO Quadrature Encoder Wiring Example



T1H-CTRIO TTL Quadrature Encoder Field Wiring




T1H-CTRIO TTL Input Wiring




T1H-CTRIO Output Wiring Schematic

The CTRIO outputs are individually isolated DC switches that can be used to break the high or the low side of a DC load.




T1H-CTRIO Stepper/Servo Drive Wiring Example




This example assumes that the Step Amplifier interface to be optocoupler LEDs (common anodes at the “OPTO Power” terminal) with internal current limiting resistors. This is a standard method, but you must consult your step amplifier documentation to ensure that this method is applicable.

Solid State Input Device Wiring to H0/H2/H4/T1H-CTRIO

NPN Field Device



PNP Field Device



INTRODUCTION TO CTRIO WORKBENCH



In This Chapter...

What is CTRIO Workbench?	3-2
Getting Started with CTRIO Workbench	3-2
Module Modes of Operation	3-5

What is CTRIO Workbench?

CTRIO Workbench is the software utility you will use to configure the CTRIO module's inputs and outputs. Workbench also lets you setup the CTRIO's built-in scaling function that will scale signals to desired engineering units, switch between the CTRIO's Program mode and Run mode, monitor I/O status and functions, and have diagnostic control of module functions.



The CTRIO Workbench utility ships with the CTRIO User Manual. You can also download the latest version free at the Host Engineering Web site: www.hosteng.com.

Installing CTRIO Workbench

The CTRIO Workbench utility installs directly from its executable file. Double click on the Setup.exe icon. The install shield will step you through the installation process. The utility installs into C:\HAPTools directory.

Several support versions of CTRIO Workbench are loaded on your PC during the installation. One is for *DirectLOGIC* PLC users (*DirectSoft32*, Rel. 3.0C, Build 71 or later is required). The other support versions are for WinPLC, EBC, PBC, DEVNETS and MODBUS users. An Offline support version is also available to create module configuration files offline.

Getting Started with CTRIO Workbench



Several paths are available to start CTRIO Workbench. All users will find CTRIO Workbench at Start>Programs>AutomationDirect Tools>CTRIO Workbench. *DirectSOFT32* users will find CTRIO Workbench under PLC (menu)>Tools>CTRIO Workbench and in the *DirectSOFT32* Launch Window Utilities menu.

Offline CTRIO Configuration

A complete CTRIO configuration file (.cwb) can be created Offline. (Refer to chapter 6 for offline addressing guidelines for some of the interface devices.) To launch the CTRIO Workbench 2 Offline version, go to Start>Programs>AutomationDirect Tools>CTRIO WB2 - Offline.

In the Workbench Offline window shown to the right, click on the Select PLC button. Select desired PLC or interface device.

The only limitations in the Offline version are that you cannot access Monitor I/O and that you cannot connect to the CTRIO from the Offline utility. Save the configuration file to disk and connect to the CTRIO using the appropriate Workbench support version, then write the file to the CTRIO






Online CTRIO Configuration

To configure the CTRIO module Online, a CTRIO must be installed in the PLC base or Terminator I/O system, and the system power must be on. Your PC communicates with the CTRIO module through the PLC or interface device port.

DirectSOFT32 Users

You will need to connect your PC to any port on a *Direct*LOGIC CPU, DCM or ECOM module. If you are linked to your CPU through *DirectSOFT32*, CTRIO Workbench will start via the existing link. If you are “disconnected” from your PLC and start CTRIO Workbench, you will be prompted to establish a link to your CTRIO module.

You will find CTRIO Workbench under PLC (menu)>Tools>CTRIO Workbench. and in the *DirectSOFT32* Launch Window Utilities menu.




WinPLC, EBC and PLC>ERM>EBC Users

You will need to connect your PC to the RJ45 Ethernet port on the WinPLC or EBC interface device directly or via hub, switch, etc. (Connect to the ST-style fiber optic port on the Hx-EBC-F units.)


Access the WinPLC and EBC support version at Start>Programs>AutomationDirect Tools>CTRIO Workbench or in the *DirectSOFT32* Launch Window Utilities menu as shown above. Select the appropriate Workbench version.

You will be prompted to establish an Ethernet link to your CTRIO module.



WinPLCs will need to be given an IP address before connecting with Workbench.

EBCs will need to have an address selected by DIP Switch or via NetEdit before connecting with Workbench.





PBC, DEVNETS and MODBUS Users

You will need to connect your PC to the RJ12 serial port on the PBC, DEVNETS or MODBUS interface device.

Access the various support versions at Start>Programs>AutomationDirect Tools>CTRIO Workbench or in the *DirectSOFT32* Launch Window Utilities menu as shown on the previous page. Select the appropriate Workbench version.


You will be prompted to establish a serial link to your CTRIO module.

Select the PC serial port Workbench will use to connect to the CTRIO module.



Successful On-line Connection



Once you are connected to your CTRIO module, you will enter the main window of CTRIO Workbench. Here, you select the CTRIO module you wish to configure by clicking on its slot number in the “Installed Modules” box. You will be able to enter Workbench’s Configuration dialog, and after successfully configuring the module you will be able to toggle the CTRIO module between Program Mode and Run Mode and enter the Monitor I/O dialog.



Module Modes of Operation

On the CTRIO Workbench main window, a single button toggles between Run Mode and Program Mode. The Module Mode indicator will tell you which mode your module is in. You can make configuration changes in either Run Mode or Program Mode, but to save your configuration to the module, you must click “Write Module” which is only active in Program Mode.


In the lower left corner of the main Workbench dialog, is the Config Status indicator. If the current configuration is different from the CTRIO and different from any saved files, the indicator will display the word “Changed.” If the current configuration has been written to the module or a file, the message will read “Same as Module,” “Same as File,” or “Same as Both.”



Program Mode - Configuring the CTRIO Module

After the configuration is created or changed in CTRIO Workbench, it must be “written” to the CTRIO module. This is accomplished by returning to the main CTRIO Workbench window and clicking on “Write Module.”

If the configuration was created using Workbench Offline version, you must connect your PC to the CTRIO module through the CPU/controller and write the configuration to the module.



*Entering program mode takes the CTRIO module offline. Input pulses are not read or processed in Program mode, and all outputs are disabled. **DirectLOGIC** CPUs will hold last value in V-memory while the CTRIO is in Program Mode.*

Run Mode - Start Processing I/O Pulses with the CTRIO Module

Selecting Run Mode causes the CTRIO module to begin processing pulses based on the I/O configuration you created.

In Run mode the CTRIO Workbench utility also allows you to monitor and verify the proper operation of inputs and outputs. You can see the count change, reset, etc. using the Monitor I/O dialog. Monitor I/O is very useful for debugging and commissioning of a new system. See chapter 7 for information on Monitor I/O.

If you are using a **DirectLOGIC** CPU, the CTRIO mode follows the CPU mode. If the CPU is placed in Run Mode, the CTRIO module will also enter Run Mode. If the CPU is placed in STOP or PROGRAM Mode, the CTRIO will enter Program Mode. The CTRIO also responds to mode changes made in Workbench and can be placed in Run Mode while the CPU is in Stop or Program Mode. The CTRIO module responds to the most recent change whether performed in Workbench or from the CPU.



The CTRIO module will not enter Run Mode if it does not have a valid configuration.

CONFIGURING THE INPUTS USING CTRIO WORKBENCH



In This Chapter...

Configure I/O Dialog Overview	4-2
Input Function Selections	4-3
Counter	4-4
Quadrature Counter	4-5
Pulse Catch	4-6
Edge Timer	4-7
Dual Edge Timer	4-8
Reset 1 and Reset 2 (Hard Resets for Counters Only)	4-9
Soft Resets	4-9
Capture 1	4-10
Inhibit 1	4-10
Introduction to the Scaling Wizard	4-11

Configure IO Dialog Overview

The Configure IO dialog is the location where input and output functions are assigned to the module. The choice of input and output functions determines which options are available.

The input and output function boxes prompt you with selections for supported functions. The Workbench software disallows any unsupported configurations.

From the main CTRIO Workbench window, click on the “Go to PROGRAM Mode” button (if in RUN Mode). Then, click on the “Config I/O” button to arrive at a dialog shown to the right. Notice that the window has a tab for each input Channel.



You don't have to be in PROGRAM mode to enter the Configure I/O dialog, however you must be in PROGRAM mode to save the configuration to the CTRIO module.


The input options are listed by function. Four boxes labeled A, B, C, and D correspond to the input terminals on the face of the module (1A-1D or 2A-2D; A-D for the H0-CTRIO).

The Output functions are listed as 0, 1, 2, and 3. These numbers correspond to the markings beside the module's output terminals (Y0-Y3; Y0-Y1 for the H0-CTRIO).


For example, you might click on “Counter” in the “A” box, then OK to return to the main Workbench window. Once you arrive back at the main window, you must click “Write Module” to save your selection to the module. The module will need to be in Program Mode to perform the Write Module operation. If you do not perform the Write Module operation (or a Write File operation) your configuration will be lost upon quitting Workbench. This applies to all changes to the module configuration.



H2, H4, T1H-CTRIO Configure I/O Dialog



H0-CTRIO Configure I/O Dialog



Input Function Selections

Supported Functions

The input channels offer the same configuration options. The module supports five primary input functions:

- Counter
- Quadrature Counter
- Pulse Catch
- Edge Timer
- Dual Edge Timer

Each of the primary functions uses one or two input terminals for making connections to field devices (plus a common). Combinations of the listed functions are possible. CTRIO Workbench disallows any unsupported configurations.

Three secondary input functions are also supported:

- Reset
- Capture
- Inhibit


Each secondary input modifies the primary input functions in some way and uses one input terminal. (Limit Out 0 and Limit Out 2 input functions are only available for use when the outputs are set to pulse output mode).

Discrete Outputs Pre-Assigned to Input Functions

CTRIO discrete outputs can be assigned to the Counter, Timer and Pulse Catch input functions within the Configure I/O dialog. The outputs respond to presets assigned by the user in the Preset Tables dialog. The presets are assigned based on the scaled value of an input, or the raw value if it has no scaled value. The CTRIO's four outputs can all be assigned to one function, or they can be grouped within functions and within channels in any manner selected by the user. See Chapter 5 for more information on using Preset Tables.

Counter Function

The CTRIO module supports up or down counting using single-ended encoders (or other single-ended pulse sources) as inputs. Encoders, proximity sensors, etc., can be connected to input A and/or input B on either channel or both channels. The C and D inputs are available to modify the A and B inputs. The C and D inputs can be used for Reset, Inhibit, or Capture. These functions are explained later in this chapter. The CTRIO discrete output(s) can be assigned to the Counter function using the Preset Tables dialog. Refer to “Creating and Using the Output Tables” section in Chapter 5 for details.




To insure proper operation, the field device wiring and the configuration must be compatible. For wiring information see Chapter 2.

The module’s four input terminals are represented by the A, B, C, and D boxes on the left side of this dialog. If you are wiring your counter input to terminal 1A, you will want to select the Channel 1 tab near the top of this window and click “Counter” in box A.


At this point, you have four decisions to make regarding your input at 1A.

1. Select count up or count down. A button, in the Function 1 box, toggles between Up and Down counting. Click the button labeled “Up” (or “Down”) to see the change to the opposite count direction.
2. Each input pulse is counted, but you are free to designate whether you want the count to register on the rising edge of the pulse, the falling edge, or both. The button with the graphical representation of a pulse toggles between these choices.
3. The Reset value is assigned by clicking and typing a value in the data input field. This value is for hardwired resets. When the hardwired reset is activated, the count value returns to the reset value.
4. The last remaining decision to be made is about scaling. Clicking the button with the ruler symbol starts the Scaling Wizard. We discuss the scaling wizard later in this chapter. The Scaling Wizard is intelligent in that it offers scaling options that are appropriate for your input selections.



Quad Counter

The CTRIO module supports quadrature counting using quadrature encoders as inputs. Connect your encoder to input A and input B on either channel. A second quadrature encoder can be connected to the other channel. The C and D inputs are available to control the quadrature input counting. The C and D inputs can be used for Reset, Inhibit, or Capture. These functions are explained later in this chapter. The CTRIO discrete output(s) can be assigned to the Quad Counter function using the Preset Tables dialog. Refer to “Creating and Using the Output Tables” section in Chapter 5 for details.




To insure proper operation, the field device wiring and the configuration must be compatible. For wiring information see Chapter 2.

Notice that the module’s four input terminals are represented by the A, B, C, and D boxes on the left side of this dialog. If you are wiring your quadrature counter inputs to terminal 1A and 1B, you will need to select the Channel 1 tab near the top of this window and click “Quad Counter” in box A. Notice that input B is now slaved to input A.

At this point, you have three decisions to make regarding your quadrature input.

1. A multiplier can be applied to the quadrature input to increase its resolution. Select “1x”, “2x”, or “4x.” [1X = pulses processed on leading edge of input A, 2X = pulses are processed on both edges of input A, 4X = pulses processed on both edges of input A and both edges of input B.]
2. The “Reset Value” is assigned by clicking in the data input field and typing in a value. When the count is reset, using any of the reset methods, the count value returns to the Reset Value. The reset options are described in more detail later in this chapter.
3. The last remaining decision to be made is about scaling. Clicking the button with the ruler symbol starts the Scaling Wizard. The Scaling Wizard is intelligent in that it offers only those scaling options that are appropriate for your input selections. We discuss the scaling wizard in greater detail later in this chapter.



Pulse Catch

The CTRIO “Pulse Catch” function allows a very short duration pulse to be qualified and lengthened to a time period long enough to guarantee that it is seen by the CPU. CPU scans necessarily vary with the length and complexity of the user’s program. A scan frequency of several milliseconds, or more, is common. A pulse that lasts less than one millisecond, is typically hard to catch during the CPU scan.


The CTRIO module’s Pulse Catch function sees the fast incoming signal and holds its status in a status bit until the CPU can see it. A discrete output(s) can also be tied to follow the Pulse Catch input.



To insure proper operation, the field device wiring and the configuration must be compatible. For wiring information see Chapter 2.

Notice that the module’s four input terminals are represented by the A, B, C, and D boxes on the left side of this dialog. If you are wiring your input to terminal 1C, you will need to select the Channel 1 tab near the top of this window and click Pulse Catch in box C.


Three selections must be made in conjunction with the Pulse Catch option.



1. First, a decision must be made whether to look for the rising edge of the pulse or the falling edge of the pulse. This is a critical decision. Careful attention should be paid to the type of output the field device generates. If the signal voltage is normally low, but a short duration pulse sends the signal to the ON state, you will want to trigger off the rising edge, and vice versa.

2. The second decision you will need to make is the minimum pulse width you want to capture. Transients below this width will not be recorded. Set this value by typing the desired value in the “Minimum Width In” field.

3. The final decision to be made is the length of pulse the CTRIO module should send in response to the input pulse. Make this setting by typing in the desired value in the “Pulse Out Width” field.




Edge Timer

The Edge Timer measures the time from the rising edge of one pulse to the rising edge of the next pulse, or the rising edge of one pulse to the falling edge of the same pulse, or the falling edge of one pulse to the falling edge of the next pulse. Encoders, proximity sensors, etc., can be connected to input C and/or input D on either channel or both channels. The CTRIO discrete output(s) can be assigned to the Timer function using the Preset Tables dialog. Refer to “Creating and Using the Output Tables” section in Chapter 5 for details.




To insure proper operation, the field device wiring and the configuration must be compatible. For wiring information see Chapter 2.



Notice that the module’s four input terminals are represented by the A, B, C, and D boxes on the left side of this dialog. If you are wiring your input to terminal 1C, you will need to select the Channel 1 tab near the top of this window and click Counter in box C.

At this point, you have four decisions to make regarding your input at 1C.

1. First, designate the pulse edges you want to measure between. There are four choices. You can measure the time from the leading edge of the upward pulse to the leading edge of the next upward pulse, or from the trailing edge of an upward pulse to the trailing edge of the next upward pulse, or from the leading edge of an upward pulse to the trailing edge of the same pulse, or, finally, from the leading edge of a downward pulse to the trailing edge of the same downward pulse.



The last option could be restated as timing from the trailing edge of an upward pulse to the rising edge of the next upward pulse.

2. The “Free Run” option is assigned by clicking in the appropriate box. If your application calls for velocity measurements to be taken at the commencement of some event, do not use Free Run. If your application calls for velocity measurement on a continuous (moving average) basis, you should use Free Run.
3. The “Enable Timeout” option is assigned by clicking in the appropriate box and specifying a Timeout period. Once the timer is enabled, the Timeout Bit is set if the time that it takes the CTRIO to see the configured input edge exceeds the specified Timeout Period. Also, if the time before the CTRIO sees the next configured edge exceeds the specified Timeout Period, the Timeout bit is set. More information about the Timeout function can be found in chapter 6.
4. The last remaining decision to be made is about scaling. Clicking the button with the tape measure symbol starts the Scaling Wizard. We discuss the scaling wizard later in this chapter. The Scaling Wizard is intelligent in that it offers scaling options that are appropriate for your input selections.

Dual Edge Timer

The Dual Edge Timer is designed to measure from a pulse edge on one incoming signal to a pulse edge on another incoming signal. The user selects whether to measure between rising edges, falling edges, etc. The choices are summarized in the tables below. The CTRIO discrete output(s) can be assigned to the Dual Edge Timer function using the Preset Tables dialog. Refer to “Creating and Using the Output Tables” section in Chapter 5 for details.

Dual Edge Timer at Function 1
Rising edge of C to rising edge of D
Rising edge of C to falling edge of D
Falling edge of C to rising edge of D
Falling edge of C to falling edge of D

Dual Edge Timer at Function 2
Rising edge of D to rising edge of C
Rising edge of D to falling edge of C
Falling edge of D to rising edge of C
Falling edge of D to falling edge of C




To insure proper operation, the field device wiring and the configuration must be compatible. For wiring information see Chapter 2.

Notice that the module’s four input terminals are represented by the A, B, C, and D boxes on the left side of this dialog. If you are wiring your inputs to terminals 1C and 1D, you will need to select the Channel 1 tab near the top of this window and click Dual Edge Timer in box C or D.

At this point, you have four decisions to make regarding your input at 1C or 1D.

1. First, designate the pulse edges you want to measure between.
2. The “Free Run” option is assigned by clicking in the appropriate box. If your application calls for velocity measurements to be taken at the commencement of some event, do not use Free Run. If your application calls for velocity measurement on a continuous basis, you should use Free Run.
3. The “Enable Timeout” option is assigned by clicking in the appropriate box and specifying a Timeout period. Once the timer is enabled, the Timeout Bit is set if the time that it takes the CTRIO to see the configured I input edge exceeds the specified Timeout Period. Also, if the time before the CTRIO sees the next configured edge exceeds the specified Timeout Period, the Timeout bit is set. More information about the Timeout function can be found in chapter 6.
4. The last remaining decision to be made is about scaling. Clicking the button with the tape measure symbol starts the Scaling Wizard. We discuss the scaling wizard later in this chapter. The Scaling Wizard is intelligent in that it offers scaling options that are appropriate for your input selections.





Reset 1 and Reset 2 (Hard Resets for Counters Only)

“Reset 1” is available only if you have selected a Counter or Quad Counter as the primary function. For example, if you have chosen either counter function (single-ended or quadrature) on terminal 1A, you will have an option of using terminal 1C for a hard reset signal. Other options are available on terminal 1D. Those options are Capture and Inhibit (see next page).


Reset 2 is available if you have selected to use terminal 1B for a counter input. Reset 2 will reset the counter connected to terminal 1B.

Two distinct types of hard resets are available. One is an edge reset. The other is a level reset. The Edge Reset sets the current count to zero on the specified edge (rising or falling) of the reset pulse (see upper example). The Level Reset resets the count to zero (as long as the reset pulse is held high (or low depending on configuration). When the reset pulse disappears, the count resumes (see lower example).

If the Reset options are not available in the Configure IO dialog, then you have selected input functions that do not use the reset modifier.



Reset 1 and Reset 2 represent hard-wired inputs to terminal C or D. An appropriate field device must be connected to the designated terminal to perform the reset function.



Soft Resets

Soft resets are available by turning on the appropriate control bit in your control program (Counters only) or by using the Reset Count function within a Discrete Output Preset Table configuration (Counters/Timers). Counter control bit resets are always level resets, meaning they hold the count at zero until the reset bit is turned off.


Capture 1

“Capture 1” is available only if you have selected a Counter or Quad Counter as the primary function. For example, if you have chosen either counter function on terminal 1A, you will have an option of using terminal 1D for a capture signal.

Capture 1 “snapshots” the current count into the 2nd DWord register (Parameter 2). The Capture feature is available with a single-ended Counter on input A or a Quad Counter on inputs A and B.



Capture 1 represents a hard-wired input to terminal D. An appropriate field device must be connected to the designated terminal to perform the capture function.





Inhibit 1

“Inhibit 1” is available only if you have selected a Counter or Quad Counter as the primary function. For example, if you have chosen either counter function on terminal 1A, you will have an option of using terminal 1D for an inhibit signal.

The “Inhibit 1” signal prevents the CTRIO from counting pulses. The Inhibit feature is available with the “A” Counter or Quad Counter on each channel.



Inhibit 1 represents a hard-wired input to terminal D. An appropriate field device must be connected to the designated terminal to perform the inhibit function.




Introduction to the Scaling Wizard

Scaling raw signals to engineering units is accomplished using the Scaling Wizard. Start the Scaling Wizard by clicking the ruler button on the Configure IO dialog. This button appears only after you select one of the Counter or Timer functions.


The Scaling Wizard options are different for the Counter functions as compared with the Timer functions. “Position” and “Rate” scaling are available when you select a Counter function. “Interval” scaling is available when you select a Timing function.

We will step through the dialogs used for each scaling type. Substitute appropriate values to set up scaling for your application.



Scaling Wizard Examples for Counter Functions

On the counter Scaling Wizard, you can select None, Position, or Rate. No scaling is accomplished if the None button is selected. Position scaling is appropriate for measuring distance, position, or size. Rate scaling is appropriate for velocity, RPM, flow, or similar rate based measurements. You may want to read the Notes and other information before leaving this window.



Position Scaling (Counter)

To select Position Scaling, click the radio button beside the word Position. Now, click Next to move to the Output Settings dialog.



On the Output Settings dialog, you will notice the field for engineering units. Enter an appropriate value for Position Scaling, for example yards, feet, meters, cubic inches, etc. Seven data types are available including BCD (to make values more easily used by *Direct*LOGIC PLCs).

Click Next, to open the Position Settings dialog. It is here that you enter the span of raw counts that equates to a span of engineering units.

The "Scaling Wizard - Output Settings" dialog box features a title bar with a close button. It contains the following elements:

- Engineering Units:** A text field containing "yds" with a note "(up to 4 characters)".
- Output Format:** A list of radio buttons:
 - Floating Point
 - Integer (rounded)
 - Integer x10 (1 implied decimal place)
 - Integer x100 (2 implied decimal places)
 - BCD (rounded)
 - BCD x10 (1 implied decimal place)
 - BCD x100 (2 implied decimal places)
- Buttons:** "Cancel", "< Back", and "Next >"

This window contains a calculator to double check the meaning of your Position Settings. Enter a value into the Raw Value field to see the equivalent value in engineering units.

The "Scaling Wizard - Position Settings" dialog box features a title bar with a close button. It contains the following elements:

- Minimum Raw Value:** Input field with "0" and "counts" label.
- Maximum Raw Value:** Input field with "1000" and "counts" label.
- Minimum Scaled Value:** Input field with "0" and "yds" label.
- Maximum Scaled Value:** Input field with "300" and "yds" label.
- Position Scaling Calculator:** A sub-dialog box with:
 - Text: "Enter a raw count value to confirm scaling configuration."
 - Raw Value:** Input field with "250" and "counts" label.
 - Scaled Value:** Input field with "75 yds".
- Buttons:** "Cancel", "< Back", and "Finish"

Rate Scaling (Counter)

To select Rate Scaling, click the radio button beside the word Rate. Now, click Next to move to the Output Settings dialog.



On the Output Settings dialog, you will notice the field for engineering units. Enter an appropriate value for Rate Scaling, for example RPM, fps, flow, etc. Seven data types are available including BCD (to make values more easily used by DirectLOGIC PLCs).

Click Next, to open the Rate Settings dialog. It is here that you enter the counts per unit of time and the time base. A scale offset is also provided to adjust the result by a constant amount.

This window contains a calculator to double check your Rate Settings. Enter a value into the Raw Value field to see the equivalent value in engineering units.

As an example, let's say you have a 1,000 pulse/revolution encoder, and you want to use it to measure RPM (of the encoder shaft). You would enter "1,000" for the Counts/unit and "minutes" as the Time Base. A check using the calculator (over a sample time of 1,000 ms = 1 second) reveals that 5,000 counts equals 300RPM.

5000 counts/1000 counts per rev = 5 revolutions;


5 revolutions/1 sec x 60 sec/1 minute= 300 RPM

Data Smoothing allows rolling averages to be taken to calculate a value.

Min = 1 sample, max = 25 samples in the rolling average.

Using the Scaling Wizard with Timer Functions

Scaling raw signals to engineering units is accomplished using the Scaling Wizard. Start the Scaling Wizard by clicking the ruler button on the Configure IO dialog. This button appears only after you select one of the Counter or Timer functions.




Interval Scaling (Timer)

To select Interval Scaling, click the radio button beside the word Interval. Now, click Next to move to the Output Settings dialog.



On the Output Settings dialog, you will notice the field for engineering units. Enter an appropriate value for Interval Scaling, for example RPM, fps, flow, etc. Seven data types are available including BCD (to make values more easily used by *DirectLOGIC* PLCs).




Click Next, to open the Interval Settings dialog. It is here that you enter the counts per unit of time and the time base. A scale offset is also provided to adjust the result by a constant amount.

This window contains a calculator to double check the meaning of your Rate Settings. Enter a value into the Raw Value field to see the equivalent value in engineering units.

Data Smoothing allows rolling averages to be taken to calculate a value.

Min = 1 sample, max = 25 samples in the rolling average.



CONFIGURING THE OUTPUTS USING CTRIO WORKBENCH



In This Chapter...

Configure IO Dialog Overview	5-2
Output Function Selections	5-3
Raw Output	5-4
Discrete Outputs	5-5
Pulse Outputs	5-8
Trapezoidal Profile	5-9
S-Curve Profile	5-10
Symmetrical S-Curve Profile	5-11
Dynamic Positioning Profile	5-12
Dynamic Velocity Profile	5-13
Home Search Profile	5-14
Additional Pulse Profiles	5-16

Configure IO Dialog Overview

The Configure IO dialog is the location where input and output functions are assigned to the module. The choice of input and output functions determines which options are available.


The input and output function boxes prompt you with selections for supported functions. The Workbench software disallows any unsupported configurations.

From the main CTRIO Workbench window, click on the “Go to PROGRAM Mode” button. Then, click on the “Config I/O” button to arrive at a dialog shown to the right. Notice that the window has a tab for each input Channel. Channel 1 and Channel 2 offer the same configuration options. Remember that the H0-CTRIO only has one input channel.


The input options are listed by function. Four boxes labeled A, B, C, and D correspond to the input terminals on the face of the module (1A-1D or 2A-2D; A-D for the H0-CTRIO).

The Output functions are listed as 0, 1, 2, and 3. These numbers correspond to the markings beside the module’s output terminals (Y0-Y3; Y0-Y1 for the H0-CTRIO).


For example, you might click on “Discrete Output” in the “0” box, then OK to return to the main Workbench window. Once you arrive back at the main window, you must click “Write Module” to save your selection to the module. The module will need to be in Program Mode to perform the Write Module operation. If you do not perform the Write Module operation (or a Write File operation) your configuration will be lost upon quitting Workbench. This applies to all changes to the module configuration.



H2, H4, T1H-CTRIO Configure I/O Dialog



H0-CTRIO Configure I/O Dialog



Output Function Selections

Supported Functions



The module supports four output functions:

- Raw
- Pulse (Step/Direction)
- Pulse (CW/CCW)
- Discrete Ch(1,2)/Fn(1,2)

Each function uses one or two output terminals for making connections to field devices (plus a common). Combinations of the listed functions are possible. CTRIO Workbench disallows any unsupported configurations.

CTRIO Memory Usage: Pulse Profiles and Preset Tables

CTRIO Workbench can create a maximum of 255 predefined Pulse Profiles. The total number of Pulse Profiles available is 255 minus the number of predefined Preset Tables. Pulse Profiles and Preset Tables are saved as File 1 through File 255. The module has 256 Total Blocks of memory allocated for Pulse Profiles and Preset Tables usage. The number of memory blocks used varies between Pulse Profiles and Preset Tables.




Raw Output

The CTRIO module supports Raw output mode. This mode allows the CPU/controller program to have direct access to the module's output points. Each output can be configured for Raw output mode and each will have a unique control bit.




To insure proper operation, the field device wiring and the configuration must be compatible. For wiring information see Chapter 2.

Refer to “Output Control Bit Definitions (Raw Mode)” on page 6-5 for Raw output control bit addressing.



The module's output terminals are represented by the 0, 1, 2, and 3 boxes (0 and 1 for the H0-CTRIO) on the right side of this dialog.




Discrete Outputs

The CTRIO module has four discrete outputs numbered Y0-Y3 (Y0-Y1 for the H0-CTRIO). The outputs respond to presets assigned by the user in the Configure IO dialog.

The presets are assigned based on the scaled value of an input, or the raw value if it has no scaled value. The four outputs can all be assigned to one function, or they can be grouped within functions and within channels in any manner selected by the user.


To assign output presets, begin by selecting the output on the Configure IO dialog. The outputs are identified based on terminal number. In the example to the right, output terminal “0” is designated for a discrete output.



Once the output selection is made, a new button appears on the Configure IO dialog. The button is labeled as shown to the right. The leading numeral represents the number of the output terminal. Clicking on the Preset button causes the Default Output Settings dialog to pop up. Default settings are loaded on power-up.




On the Output Settings dialog, select “Use Single Preset.” We will discuss Preset Tables later in this chapter. Now, click OK to arrive at the Edit Preset Entry dialog.



discuss Preset Tables later in this chapter. Now, click OK to arrive at the Edit Preset Entry dialog.

Six output functions are available (as shown in the figure below). Set the preset value in engineering units if the signal has been scaled. Set the preset value in raw count if the signal has not been scaled. We discuss scaling in chapter 4. Pulse ON and Pulse OFF require a Pulse Time setting. The Pulse Time is set in msec (1,000 sec = 1 msec)



Output Function Definitions	
Set	Writes output ON (maintained)
Reset	Writes output above OFF
Pulse On	Writes output ON for specified time
Pulse Off	Writes output OFF for specified time
Toggle	Changes state of output
Reset Count	Resets the count to Preset Value



Creating and Using the Output Preset Tables


Preset tables can be used only when the corresponding input is configured for a timer or quad/counter that is not scaled or if a counter is set to Position scaling.

To create tables of presets, click the Preset Tables button on the main Workbench dialog. This will open the Output Preset Tables dialog. To create a new table, click Add (or Edit). This will open the Edit Preset Table dialog. Build a Preset Table by adding preset entries one at a time. Click Add Preset (or Edit Preset) to open the Edit Preset Entry dialog.




The preset tables work similar to an event drum, not a programmable limit switch. For example, in the Edit Preset Table dialog below, the output is SET at count 100. Once the output is SET, if the count drops below 100, the output will not go OFF, it will remain SET. Once a step is complete, the focus is on the next step and that step only.

On the Edit Preset Entry dialog, select one of the six Output Functions. Set the preset value in engineering units if the signal has been scaled. Set the preset value in raw count if the signal has not been scaled. We discuss scaling elsewhere in this chapter. Pulse ON and Pulse OFF require a Pulse Time setting.



The Pulse Time is set in ms (1,000 ms = 1 sec). For a description of the Output Functions see page 5-6.

To set a particular table as the default table, use the Default Output Settings dialog described on page 5-6.



Using the Discrete Outputs in Level Mode

If a Counter or Timer function is scaled to produce a rate, alarm level settings can be used to trigger discrete outputs at values predetermined by the user.

Click the Level button on the Configure I/O dialog. This will open the Default Output Settings (Level Mode) dialog.



The alarm level is set within the Default Output Settings (Level Mode) dialog.


Also, a deadband percentage (in tenths of a percent) can be set to prevent the output from changing too frequently (chattering) near the Rate Level threshold.

“ON when greater” condition example:

Consider a Discrete Output set to turn ON when a level gets to 500 rpm with a 10% deadband. The output will turn ON when the level gets to 100. If the level drops, the output will stay on until the level drops below 450 rpm, where it will turn OFF.

“OFF when less” condition example:

Consider a Discrete Output set to turn “OFF when less” at 500. When the level gets to 500, the output turns OFF. If the level rises again, the output will stay OFF until the level gets to 550, where it will turn ON.



Pulse Outputs




The CTRIO module offers up to two axes of motion control (Y0 and Y1 as an axis and/or Y2 and Y3 as an axis). The H0-CTRIO has one axis of motion control (Y0 and Y1). The outputs can be configured for CW/CCW, or step and direction operation. The outputs respond to profiles defined by the user and called by the user control program. The following pulse profiles are supported:

- Trapezoid
- S-Curve
- Symmetrical S-Curve
- Dynamic Positioning
- Dynamic Velocity
- Home Search


There are three additional pulse profiles that are available to use that are not created using the Pulse Output Profiles Tables. These profiles: Velocity Mode, Run to Limit Mode and Run to Position Mode are discussed at the end of this chapter.

Creating Pulse Output Profile Tables

To create Pulse profiles, click the Pulse Profiles button on the main Workbench dialog. This will open the Pulse Profiles Tables dialog. To create a new profile, click Add (or Edit). This will open the Edit Pulse Profile dialog.




On the Edit Pulse Profile dialog, select one of the six Pulse Profile Types. This dialog is used to name and define the pulse profile parameters. The various parameter fields contain typical default values. Workbench will disallow any invalid parameter entries.



Trapezoidal Profile

The Trapezoidal profile changes the velocity in a linear fashion from the specified Start Frequency until the specified target Position Frequency is reached. During decelerating, the velocity changes in a linear fashion from the specified Position Frequency until the specified End Frequency and Total Pulses is reached.



Total Pulses: The total amount of output pulses that will be generated during the Trapezoidal profile.

Accel Time: The amount of time required for the Start Frequency to ramp up the Position Frequency.

Decel Time: The amount of time required for the Position Frequency to ramp down to the End Frequency.


Start Freq: The frequency at which the Trapezoidal profile will begin.

Pos Freq: The target frequency to which the Start Frequency rises.

End Freq: The frequency to which the Position Frequency falls.

S-Curve Profile

The S-Curve profile can be used for applications that are sensitive to sudden changes in position or velocity, resulting with vibrations or jerky reactions. The S-Curve profile provides more controlled acceleration and deceleration periods than the Trapezoidal profile by increasing the transition times.



Total Pulses: The total amount of output pulses that will be generated during the Trapezoidal profile.

Accel Time: The amount of time required for the Start Frequency to ramp up the Position Frequency.

Decel Time: The amount of time required for the Position Frequency to ramp down to the End Frequency.

Start Freq: The frequency at which the Trapezoidal profile will begin.

Pos Freq: The target frequency to which the Start Frequency rises.

End Freq: The frequency to which the Position Frequency falls.


Min Freq Change: The amount of calculated frequency change that must take place before stepping to the next frequency.

Min Entry Time: The amount of time spent in each step.

Symmetrical S-Curve Profile

The Symmetrical S-Curve profile can also be used for applications that are sensitive to sudden changes in position or velocity, resulting with vibrations or jerky reactions. The Symmetrical S-Curve provides more controlled acceleration and deceleration periods than a Trapezoidal profile by increasing the transition times.

The S-Curve and Symmetrical S-Curve profiles differ in that the Symmetrical S-Curve has symmetrical acceleration and deceleration profiles. The Decel Time and End Frequency are determined by the Accel Time and Start Frequency. The Symmetrical S-Curve uses less memory than the S-Curve profile.



Total Pulses: The total amount of output pulses that will be generated during the Trapezoidal profile.

Accel Time: The amount of time required for the Start Frequency to ramp up the Position Frequency. This also represents the deceleration time.

Start Freq: The frequency at which the Trapezoidal profile will begin. This also represents the end frequency.


Pos Freq: The target frequency to which the Start Frequency rises.

Min Freq Change: The amount of calculated frequency change that must take place before stepping to the next frequency

Min Entry Time: The amount of time spent in each step.

Dynamic Positioning Profile

The Dynamic Positioning profile is a trapezoidal profile with identical acceleration/deceleration rates and identical starting/stopping frequencies. The maximum target frequency is specified. The target position (# of output pulses) is located in a memory register in the CPU/controller. Once the position is reached, the output is disabled and a new target position can be specified in the memory register.




Accel Rate: The rate at which the Minimum Frequency will ramp up to the Maximum Frequency. This sets the deceleration rate as well.

Minimum Freq: The frequency at which the profile will begin.

Maximum Freq: The target frequency to which the Minimum Frequency rises.

Dynamic Velocity Profile

The Dynamic Velocity profile is a trapezoidal profile with the direction acceleration and deceleration rates specified. The target velocity is located in a memory register in the CPU/controller. Once the CPU/controller initiates the profile, output pulses will be generated at the target velocity until the CPU/controller disables the output pulses.



Clockwise Accel Rate: The clockwise rate at which the output will ramp up from 0pps to the target velocity that is specified in the CPU/controller memory register.

Clockwise Decel Rate: The clockwise rate at which the output will ramp down from the target velocity that is specified in the CPU/controller memory register to 0pps.

Counter-Clockwise Accel Rate: The counter-clockwise rate at which the output will ramp up from 0pps to the target velocity that is specified in the CPU/controller memory register.

Counter-Clockwise Decel Rate: The counter-clockwise rate at which the output will ramp down from the target velocity that is specified in the CPU/controller memory register to 0pps.


Home Search Profile

The Home Search profile is used to “*find the home position*”, which is usually a reference point to which the object being moved can return upon command at any time during or after the execution of a positioning profile.

There are several Home Search routines to choose from, all with the option to designate whether you want Limit 1 and/or Limit 2 (a CTRIO discrete input) to register on the rising edge, falling edge, high level or low level signal. Limit 1 and Limit 2 can be the opposite edges of the same physical CTRIO input.



The Home Search profile requires that CTRIO inputs C and/or D are configured for Limit Out 0 or Limit 2. This is done using the Configure I/O dialog.



Frequency 1: The frequency at which the Home Search will begin.

Limit 1: Home Search Frequency 1 will run to CTRIO input Limit 1 and stop unless Frequency 2 is enabled.


Frequency 2: (if enabled) Once Limit 1 is reached, the pulse output will continue at Frequency 2 until CTRIO Limit 2 is reached or pulse Count is reached at Frequency 2.

Limit 2: (if enabled) Home Search Frequency 2 will run to CTRIO input Limit 2 and stop.


Count: (if enabled) The number of output pulse counts generated at Frequency 2 before terminating.

Home Search Routines


1. Run to Limit 1 at Frequency 1.




2. Run to Limit 1 at Frequency 1, then continue to Limit 2 at Frequency 2.




3. Run to Limit 1 at Frequency 1, then reverse to Limit 2 at Frequency 2.



4. Run to Limit 1 at Frequency 1, then continue to Count at Frequency 2.



5. Run to Limit 1 at Frequency 1, then reverse to Count at Frequency 2.




Additional Pulse Profiles

Three additional pulse profiles are available to use that are *not* defined or created using the Pulse Profiles Table dialog, however the output(s) must be configured for Pulse (Step/Direction) or Pulse (CW/CCW) using the Configure I/O dialog. The profile parameters are stored in the CPU/controller memory registers. The profiles are briefly described below and will be discussed in detail in Chapter 6. With all three profiles, the output is a step response output to the specified target frequency, thus no acceleration/deceleration parameters are configured.

Velocity Mode: User specifies the target frequency, pulse train duty cycle and the step count. Once initiated, the output will begin pulsing at the target frequency and continue until the step count is reached. With a step count of 0xFFFFFFFF, the pulse output will continue indefinitely until the control program disables the output.

Run to Limit Mode: User specifies target frequency and pulse train duty cycle. A CTRIO module input (C or D) must be configured as a Limit input. When the Limit is reached the pulse output is disabled.

Run to Position Mode: User specifies target frequency, pulse train duty cycle and target position. The current position is obtained from the specified Input Function (i.e. Quadrature counter). When the current position reaches the specified target position, the pulse output is disabled. The comparing of the current and target position can be based on “greater than or equal to” or “less than” values.



PROGRAM CONTROL



CHAPTER 6

In This Chapter...

Input Memory Map for Data Transfers from CTRIO to CPU	6-2
Output Memory Map for Data Transfers from CPU to CTRIO	6-4
I/O Map Dialog	6-7
Addressing Conventions	6-15
Input Function Status/Control Bits and Parameters	6-16
Input Functions	6-19
Runtime Changes to CTRIO Configured Preset Tables	6-23
Pulse Output Status/Control Bits and Command Codes	6-27
Pulse Output Profiles	6-31
System Functions	6-48

Input Memory Map for Data Transfers from CTRIO to CPU

The following table shows which memory locations are used for memory transfers from the CTRIO module to the CPU. The starting memory location is defined by the user in the I/O Map within CTRIO Workbench. If you are using the *DirectLOGIC* CPU, you will use the memory address offsets in the second column. If you are using an H2-WinPLC, EBC, PBC, MODBUS, or DEVNETS in the CPU slot, you will use the non-PLC offsets in column one.

Data Type and Offset WinPLC, EBC, PBC, DEVNETS, MODBUS	Address for Inputs (DirectLOGIC)	Definition	Format	Bytes
dwX0	n+0	Ch 1/Fn 1 Parameter 1	DWord	4
dwX1	n+2	Ch 1/Fn 1 Parameter 2	DWord	4
dwX2	n+4	Ch 1/Fn 2 Parameter 1	DWord	4
dwX3	n+6	Ch 1/Fn 2 Parameter 2	DWord	4
dwX4	n+10	Ch 2/Fn 1 Parameter 1	DWord	4
dwX5	n+12	Ch 2/Fn 1 Parameter 2	DWord	4
dwX6	n+14	Ch 2/Fn 2 Parameter 1	DWord	4
dwX7	n+16	Ch 2/Fn 2 Parameter 2	DWord	4
bX0...7 bX8...15	n+20	Ch 1/Fn 1 Status (Low Byte) Ch 1/Fn 2 Status (High Byte)	Word	2
bX16...23 bX24...31	n+21	Ch 2/Fn 1 Status (Low Byte) Ch 2/Fn 2 Status (High Byte)	Word	2
bX32...39 bX40...47	n+22	Output 0 Status (Low Byte) Output 1 Status (High Byte)	Word	2
bX48...55 bX56...63	n+23	Output 2 Status (Low Byte) Output 3 Status (High Byte)	Word	2
bX64..71 bX72...79 bX80...87 bX88 95	n+24	System Functions Read/Write CTRIO Internal Registers (see p. 6-6 for bit definitions)	DWord	4

Input (n) Parameter Definitions

44 Total
Bytes

Parameter values are in Decimal format.

Configured Function from CTRIO Workbench	Parameter 1 Contents DWORD	Parameter 2 Contents DWORD
Non-scaled Counter	Raw Input Value	Not Used
Scaled Counter	Scaled Value (pos. or rate)	Raw Value
Non-scaled Counter with Capture	Raw Value	Captured Value
Scaled Counter with Capture	Scaled Value (pos. or rate)	Captured Value
Non-scaled Timer	Previous Time (us)	In Progress Time (us)
Scaled Timer	Scaled Interval (rate)	In Progress Time (us)
Pulse Catch	Not Used	Not Used



For **DirectSOFT32** users: the **I/O Map** dialog displays the exact memory locations in use by the **CTRIO** module. Within the **I/O Map** dialog you can print out a report of memory loctions in use.

Input Function Status Bit Definitions

Input function offsets are listed in the order of Ch1/Fn1, Ch1/Fn2, Ch2/Fn1, Ch2/Fn2

Ch(x)/Fn(x) Status Bits (transfers from CTRIO to CPU)	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets DirectLOGIC PLCs
Count Capture Complete Bit	0, 8, 16, 24	20.0, 20.8, 21.0, 21.8
Timer Capture Start	0, 8, 16, 24	20.0, 20.8, 21.0, 21.8
Timer Capture Complete (Timing) OR At Reset Value (Counting)	1, 9, 17, 25	20.1, 20.9, 21.1, 21.9
Timer "Timed Out" Bit	2, 10, 18, 29	20.2, 20.10, 21.2, 21.10
Pulse Catch Output Pulse State	0, 8, 16, 24	20.0, 20.8, 21.0, 21.8
Pulse Catch Start	1, 9, 17, 25	20.1, 20.9, 21.1, 21.9

Output Status Bit Definitions (for Preset Table Control)

Output Status Offsets are listed in the order of the Output 0 - Output 3.

Output(x) Status Bits (transfers from CTRIO to CPU)	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets DirectLOGIC PLCs
Command Error	38, 46, 54, 62	22.6, 22.14, 23.6, 23.14
Command Complete	39, 47, 55, 63	22.7, 22.15, 23.7, 23.15

Output Status Bit Definitions (Pulse Output)

Output Status Offsets are listed in the order of the Output 0/1, 2/3.

Status Bit CTRIO to CPU	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V memory Offsets from Input Start (octal)
Output Enabled	32, 48	22.0, 23.0
Position Loaded	33, 49	22.1, 23.1
Output Suspended	34, 50	22.2, 23.2
Output Active	36, 52	22.4, 23.4
Output Stalled	37, 53	22.5, 23.5
Command Error	38, 54	22.6, 23.6
Command Complete	39, 55	22.7, 23.7

Output Memory Map for Data Transfers from CPU to CTRIO

The following table shows which memory locations are used for memory transfers from the CPU module to the CTRIO. The starting memory location is defined by the user in the I/O Map within CTRIO Workbench. If you are using a *Direct*LOGIC CPU, you will use the memory address offsets in the second column. If you are using a WinPLC, EBC, PBC, DEVNETS or MODBUS interface, you will use the non-PLC offsets in column one.

Data Type and Offset: WinPLC, EBC, PBC, DEVNETS, MODBUS	Address for Inputs (DirectLOGIC)	Definition	Format	Bytes
dwY0	n+0	Output 0 Parameter 3	DWord	4
dwY1	n+2	Output 1 Parameter 3	DWord	4
dwY2	n+4	Output 2 Parameter 3	DWord	4
dwY3	n+6	Output 3 Parameter 3	DWord	4
wY0	n+10	Output 0 Command	Word	2
wY1	n+11	Output 0 Parameter 1	Word	2
wY2	n+12	Output 0 Parameter 2	Word	2
wY3	n+13	Output 1 Command	Word	2
wY4	n+14	Output 1 Parameter 1	Word	2
wY5	n+15	Output 1 Parameter 2	Word	2
wY6	n+16	Output 2 Command	Word	2
wY7	n+17	Output 2 Parameter 1	Word	2
wY8	n+20	Output 2 Parameter 2	Word	2
wY9	n+21	Output 3 Command	Word	2
wY10	n+22	Output 3 Parameter 1	Word	2
wY11	n+23	Output 3 Parameter 2	Word	2
bY0...7 bY8...15	n+24	Ch 1/Fn 1 Control (Low Byte) Ch 1/Fn 2 Control (High Byte)	Word	2
bY16...23 bY24...31	n+25	Ch 2/Fn 1 Control (Low Byte) Ch 2/Fn 2 Control (High Byte)	Word	2
bY32...39 bY40...47	n+26	Output 0 Control (Low Byte) Output 1 Control (High Byte)	Word	2
bY48...55 bY56...63	n+27	Output 2 Control (Low Byte) Output 3 Control (High Byte)	Word	2
bX64...71 bX72...79 bX80...87 bX88 95	n+30	System Functions Read/Write CTRIO Internal Registers (see p. 6-6 for bit definitions)	DWord	4

Output (n) Parameter Definitions (Parameters are in decimal format)

52 Total Bytes

Configured Profile from CTRIO Workbench	Parameter 1 Contents WORD	Parameter 2 Contents WORD	Parameter 3 Contents DWORD
Trapezoidal	File # of stored profile	Not Used	Not Used
S-Curve, Symmetrical S-Curve	File # of stored profile	Not Used	Not Used
Dynamic Positioning	File # of stored profile	Not Used	Target Position
Dynamic Velocity	File # of stored profile	Not Used	Target Velocity
Home Search	File # of stored profile	Not Used	Not Used



For **DirectSOFT32** users: the I/O Map dialog displays the exact memory locations in use by the CTRIO module. Within the I/O Map dialog you can print out a report of memory locations in use.

Output (n) Parameter Definitions (Parameters are in decimal format unless specified)

Profiles Completely Controlled by User Program	Parameter 1 Contents WORD	Parameter 2 Contents WORD	Parameter 3 Contents DWORD
Velocity Mode	Initial Frequency	Duty Cycle	Number of Pulses (Hex)
Run to Limit Mode	Initial Frequency	Input Edge / Duty Cycle(Hex)	Not Used
Run to Position mode	Initial Frequency	Input Function Comparison and Duty Cycle (Hex)	Input Function Comparison Value

Input Function Control Bit Definitions

Input function offsets are listed in the order of Ch1/Fn1, Ch1/Fn2, Ch2/Fn1, Ch2/Fn2

Ch(n)/Fn(n) Control Bits (transfers from CPU to CTRIO)	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets DirectLOGIC PLCs
Enable Count Capture	0, 8, 16, 24	24.0, 24.8, 25.0, 25.8
Enable Timer Capture	0, 8, 16, 24	24.0, 24.8, 25.0, 25.8
Enable Pulse Catch	0, 8, 16, 24	24.0, 24.8, 25.0, 25.8
Reset	1, 9, 17, 25	24.1, 24.9, 25.1, 25.9

Output Control Bit Definitions (for Preset Table Control)

Output Control Offsets are listed in the order of the Output 0 - Output 3.

Output(n) Control Bits (transfers from CPU to CTRIO)	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets DirectLOGIC PLCs
Enable Output	32, 40, 48, 56	26.0, 26.8, 27.0, 27.8
Process Command	39, 47, 55, 63	26.7, 26.15, 27.7, 27.15

Output Control Bit Definitions (Pulse Output)

Pulse output control Offsets are listed in the order of Outputs 0/1, 2/3.

Output Control Bit transfers from CPU to CTRIO	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V memory Offsets from Output Start (octal)	Read as:
Enable Output	32, 48	26.0, 27.0	Level
Go to Position	33, 49	26.1, 27.1	Rising Edge
Suspend Output	34, 50	26.2, 27.2	Level
Direction	36, 52	26.4, 27.4	Level
Process Command	39, 55	26.7, 27.7	Rising Edge

Output Control Bit Definitions (Raw Mode)

Output Control Offsets are listed in the order of the Output 0 - Output 3.

Output(n) Control Bits (transfers from CPU to CTRIO)	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets DirectLOGIC PLCs
Enable Output	32, 40, 48, 56	26.0, 26.8, 27.0, 27.8

System Functions Status Bit Definitions

From Table on page 6-2, *Direct*LOGIC Offset (n+24)

Status Bits (transfers from CTRIO to CPU)	V-memory Offsets DirectLOGIC PLCs
System Command Error	24.6
System Command Complete	24.7
Ch1 A	25.0
Ch1 B	25.1
Ch1C	25.2
Ch1D	25.3
Ch2 A	25.4
Ch2 B	25.5
Ch2 C	25.6
Ch2 D	25.7
Out 0 Active	25.8
Out 0 Mode	25.9
Out 1 Active	25.10
Out 1 Mode	25.11
Out 2 Active	25.12
Out 2 Mode	25.13
Out 3 Active	25.14
Out 3 Mode	25.15

System Functions Control Bit Definitions


From Table on page 6-4, *Direct*LOGIC Offset (n+30)

Control Bits (transfers from CPU to CTRIO)	V-memory Offsets DirectLOGIC PLCs
Process System Command	30.7

I/O Map Dialog

The I/O Map dialog is accessible from the main Workbench dialog. On the main Workbench dialog, click the button labeled I/O Map.

The I/O Map dialog divides the controller I/O memory used by the CTRIO module into three groups: Input Functions, Output Functions and System Functions.




Just below the Map Display Mode field, you will see tabs to switch between Input Functions, Output Functions and System Functions.

Click on the Input Functions tab or Output Functions tab to display the CTRIO module's assigned input or output functions (quad counter, pulse catch, pulse out, discrete out, etc.). For each input and/or output function assigned, the I/O Map dialog displays the Input Data (CTRIO > Controller) addresses and Output Data (Controller > CTRIO) addresses based on the Map Display Mode and the starting I/O addresses specified. The memory map addresses displayed correspond to the offset addresses shown in the tables on the previous pages.

Click on the System Functions tab to display the System Functions addressing. The command bits are used when reading from and writing to the CTRIO's internal registers. The other bits can be used to monitor the status of each individual I/O point on the module.

I/O Map with *DirectLogic* PLC (2 ranges mode)


When using the CTRIO module with a *DirectLogic* PLC, enter the starting V memory location for the inputs and outputs in the appropriate fields at the top of the IO Map dialog. In the I/O Map dialog shown below, note that the Input, Output and Systems Functions addresses shown are in word and bit-of-word formats. Thus, word and bit-of-word addressing will need to be used in the ladder logic program to address the CTRIO's control and status words/bits.



I/O Map with *DirectLogic* PLC (4 ranges mode)

When using the CTRIO module with a *DirectLogic* PLC in 4 ranges mode, enter the starting V memory location for the *word* inputs and outputs and the starting V memory location for the *bit* inputs and outputs. Control relays (V40600 range) would usually be used for bit control.

In the I/O Map dialog below, note that Input, Output and Systems Functions addresses shown are in word and Control Relay formats. Thus, word and Control Relay addressing will need to be used in the ladder logic program to address the CTRIO control and status words/bits. Remember that the CTRIO will consume the address ranges listed in all four range fields.



I/O Map with *DirectLogic* PLC with CTRIO in ERM/EBC Network

When using the CTRIO module with a *DirectLogic* PLC with the CTRIO module in an ERM/EBC network, first configure the ERM network using the ERM Workbench utility. Then, from ERM Workbench, enter the CTRIO's starting input and output V-Map addresses into the CTRIO Workbench's I/O Map starting V memory location for the *bit* inputs and outputs.



Note: If there is an 8-pt. discrete I/O module preceding the CTRIO module in the EBC base, enter the the appropriate starting V-memory bit I/O address in CTRIO Workbench with a V40xxx.8 address as shown in I/O Map example below to the right. This corrects the word offset created by the 8-pt. discrete I/O module. In the example below to the left, note that V40416 Hi(8-15) is the starting ERM Workbench CTRIO input V-Map location due to the 8-pt. discrete input module preceding the CTRIO module.

See Note Above

I/O Module	I/O Points	PLC Slot	PLC End	V-Map	Notes
ERM Slave Bus	408	1	1	V4014	
ERM Slave Input	400	2	2	V4015	
Double Slave Channel Bus	108	3	3	V4014	
40 EBC					
12 Discrete Input	120	4	4	V4015-4016.7	
80 Discrete Input	120	5	5	V4016-4017.7 (Hi(8-15))	
12 Word Output	120	6	6	V2100	
80 Discrete Input	120	7	7	V2101	
4 Discrete Word Output	120	8	8	V2102	
16 Discrete Output	160	9	9	V4025	

I/O Map with EBC/WinPLC

When using the CTRIO module in an EBC/WinPLC system (non PLC system), the addressing will be shown as Native EBC/WinPLC addresses or if using Think & Do, the addressing can be shown as Native Think & Do addresses. Just click on the desired mode in the Map Display Mode field. The 8-pt module offset described in the note above does not apply to EBC/WinPLC or EBC/Think&Do systems.



I/O Map with an H2-PBC or T1H-PBC Profibus DP Controller

When using the CTRIO module with an H2-PBC or T1H-PBC native Profibus addressing will be displayed in the I/O Map as shown below.

For the T1H-PBC, the first two output bytes of memory are automatically reserved for the Hot Swap base-rescan feature. The H2-PBC does not support the Hot Swap feature.

H2-PBC IO Map

T1H-PBC IO Map




Note that output bytes 0-1 are reserved for the Hot Swap base rescan feature.

Creating an offline file for H2/T1H-CTRIO module

For the T1H-PBC, enter a 2 byte Output Offset to accommodate memory used by the Hot Swap base-rescan feature. This does not apply to an H2-PBC system. The example shown below assumes the T1H-CTRIO module is the first module in the system.


The CTRIO modules consume 44 bytes of input memory and 52 bytes of output memory. The maximum amount of I/O memory per H2/T1H-PBC station is 244 input bytes and 242 output bytes. You may need to refer to the Profibus User Manuals (H2-PBC-M / T1H-PBC-M) for information on bytes used by discrete and/or analog I/O modules to be able to determine the appropriate Starting input and output byte offset addresses for the CTRIO module.



For the T1H-PBC, enter a 2 byte Output Offset to accommodate memory used by the Hot Swap base-rescan feature.

I/O Map with a T1K-DEVNETS DeviceNet Controller

When using the T1H-CTRIO module with The T1K-DEVNETS controller, I/O Map will display native DeviceNet addressing as shown below.



Creating an offline file for T1H-CTRIO with T1K-DEVNETS:

The CTRIO module I/O memory is accessed by the DeviceNet master using Intelligent I/O Input Object and Intelligent I/O Output Object commands. The Input and Output Objects consist of a unique Class, Instance, and Attribute. Each CTRIO module consumes 64 bytes of input registers and 64 bytes of output registers. Instance refers to the CTRIO's position with respect to the T1K-DEVNETS controller and other CTRIO modules in the system. The first CTRIO module from the controller would be Instance 1. The second CTRIO module from the controller would be Instance 2 and so on.

Intelligent I/O Input Object (Class 109): Instance Attribute

Instance	Attribute	Bytes	Data			Address	Service
			MSB		LSB		
1-16	3	64	07	-----	00	+00	Get
			17	-----	10	+01	
			27	-----	20	+02	
			37	-----	30	+03	
			:		:	:	
			767	-----	760	+62	
			777	-----	770	+63	

Common Service

Service Code	Common Service
0Eh	Get_Attribute_Single

Intelligent I/O Input Object (Class 110): Instance Attribute

Instance	Attribute	Bytes	Data			Address	Service
			MSB		LSB		
1-16	3	64	07	-----	00	+00	Set
			17	-----	10	+01	
			27	-----	20	+02	
			37	-----	30	+03	
			:		:	:	
			767	-----	760	+62	
			777	-----	770	+63	

Common Service


Service Code	Common Service
10h	Set_Attribute_Single

I/O Map with a T1K-MODBUS Modbus RTU Controller


When using the T1H-CTRIO module with a T1K-MODBUS controller configured for *Direct*LOGIC addressing mode, enter the Starting V memory address for the inputs and outputs based on the CTRIO's position with respect to the T1K-MODBUS controller and other CTRIO modules in the system. The example below on the left assumes the T1H-CTRIO is the first intelligent module following the T1K-MODBUS controller.

When using the T1H-CTRIO module with a T1K-MODBUS controller configured for 585/985 addressing mode, enter the Starting Modbus register address for the inputs and outputs based on the CTRIO's position with respect to the T1K-MODBUS controller and other CTRIO modules in the system. The example below on the right assumes the T1H-CTRIO is the first intelligent module in following the T1K-MODBUS controller.

DirectLOGIC PLC Addressing Mode



Modbus 585/985 Addressing Mode




T1H-CTRIO Module in System		<i>Direct</i> LOGIC Addressing Mode	585/985 Addressing Mode
1 st	Input	V400-V437	33001-33033
	Output	V2000-V2037	43001-43033
2 nd	Input	V440-V477	33034-33065
	Output	V2040-V2077	43034-43065
3 rd	Input	V500-V537	33066-33097
	Output	V2100-V2137	43066-43097
4 th	Input	V540-V557	33098-33129
	Output	V2140-V2177	43098-43129
5 th	Input	V600-V637	33130-33161
	Output	V2200-V2237	43130-43161
6 th	Input	V640-V677	33162-33193
	Output	V2240-V2277	43162-43193
7 th	Input	V700-V737	33194-33225
	Output	V2300-V2377	43194-43225
8 th	Input	V740-V777	33226-33257
	Output	V2340-V2377	43226-43257

Printing a Memory Map Report

You can print an I/O Memory Map Report from the I/O Map dialog or save as a (.txt) file. Click on the Report button located near the bottom of the I/O Map dialog to display the Memory Map Report dialog.




The addresses listed in the Memory Map Report are a combination of the Input Functions, Output Functions and Systems Functions addresses shown in the I/O Map dialog. It is very convenient to have a printed list of the CPU/controller I/O memory used by the CTRIO module when attempting to write the control program.




Exporting to DirectSOFT

You can export a (.csv) file containing addressing and nicknames used in the I/O Map dialog. Click on the Export button located near the bottom of the I/O Map dialog to display the Export to DirectSOFT dialog shown below on the left.



The (.csv) file (shown below on right) contains a combination of the Input Functions, Output Functions and Systems Functions addressing and nicknames shown in the I/O Map dialog. This file can be imported into your DirectSOFT ladder logic program (DirectSOFT32>File>Import>Element Documentation).

If you have more than one CTRIO module in a system and intend to create a (.csv) file for more than one module, use the Add Prefix or Add Suffix option to distinguish one module's nicknames from the others. For example, add add prefix or suffix "S1" to identify the CTRIO module's nicknames in slot 1.



	A	B	C	D	E	F	G	H	I
1	V000	C1F1_CurCount	Current Count						
2	E020.1	C1F1_AtResVal	At Reset Value						
3	E054.1	C1F1_Reset	Reset						
4	V004	C1F2_PrevTime	Previous Time						
5	V006	C1F2_Timer	Timer						
6	E020.8	C1F2_CaptStt	Captured Start						
7	E020.9	C1F2_CaptCmplt	Capture Complete						
8	E020.10	C1F2_TimerOut	Timer Out						
9	E054.8	C1F2_EnablCpt	Enable Capture						
10	E022.0	Out0_OutEnbl	Output Enabled						
11	E022.1	Out0_PostLoad	Position Loaded						
12	E022.2	Out0_OutSuspend	Output Suspended						
13	E022.4	Out0_OutActiv	Output Active						
14	E022.5	Out0_OutStall	Output Stalled						
15	E022.6	Out0_CmdError	Cmd Error						
16	E022.7	Out0_CmdCmplt	Cmd Complete						
17	V040	Out0_CmdCode	Command Code						
18	V041	Out0_Param1	Parameter 1						
19	V042	Out0_Param2	Parameter 2						
20	V000	Out0_Param3	Parameter 3						
21	E066.0	Out0_EnablOut	Enable Output						
22	E066.1	Out0_GetPos	Get Position						
23	E066.2	Out0_Suspend	Suspend Output						
24	E066.4	Out0_Direction	Direction						

Addressing Conventions

(with V-memory Examples for *DirectLOGIC* PLCs)

Example for Bit-accessed Data in PLC CPUs



In this example, the V-memory location V2524 contains a value equal to 514 in decimal.

514 decimal = 0202 Hex = 0000 0010 0000 0010 binary

The bit V2524.1 refers to the 2nd to the least significant bit (set to 1 in this example).

Likewise, V2524.9 refers to bit number 9, the 10th from the least significant bit (also set to 1 in this example).

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
V2524	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0

V2524.9 = 1 
V2524.1 = 1 

Addressing High and Low Byte of Word Parameters

In the following example, the V-memory location V2510 contains a value equal to 3 (decimal) in the high byte and 10 (decimal) in the low byte.

3 decimal = 03 Hex = 0000 0011 binary in the high byte, and

10 decimal = 0A Hex = 0000 1010 binary in the low byte.

This example could represent the Command Code “Edit Table Entry.” The value 03 (Hex) would represent the File number in the high byte, and the 0A (Hex) would represent the remainder of the Command Code in the low byte.

Bit	High Byte								Low Byte							
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
V2510	0	0	0	0	0	0	1	1	0	0	0	0	1	0	1	0

High Nibble
Low Nibble
High Nibble
Low Nibble

Addressing High and Low Word of DWord Parameters

Double Word parameters are addressed in a similar fashion to the high and low bytes of a Word Parameter. For example, a DWord that begins in V2300 consumes both V2300 and V2301. The Low Word is V2300, and the High Word is V2301.

Input Function Status/Control Bits and Parameters

Input Function Status Bit Definitions

Input function offsets are listed in the order of Ch1/Fn1, Ch1/Fn2, Ch2/Fn1, Ch2/Fn2

Ch(x)/Fn(x) Status Bits (transfers from CTRIO to CPU)	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets DirectLOGIC PLCs
Count Capture Complete Bit	0, 8, 16, 24	20.0, 20.8, 21.0, 21.8
Timer Capture Start	0, 8, 16, 24	20.0, 20.8, 21.0, 21.8
Timer Capture Complete (Timing) OR At Reset Value (Counting)	1, 9, 17, 25	20.1, 20.9, 21.1, 21.9
Timer "Timed Out" Bit	2, 10, 18, 29	20.2, 20.10, 21.2, 21.10
Pulse Catch Output Pulse State	0, 8, 16, 24	20.0, 20.8, 21.0, 21.8
Pulse Catch Start	1, 9, 17, 25	20.1, 20.9, 21.1, 21.9

Input Function Control Bit Definitions

Input function offsets are listed in the order of Ch1/Fn1, Ch1/Fn2, Ch2/Fn1, Ch2/Fn2

Ch(n)/Fn(n) Control Bits (transfers from CPU to CTRIO)	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets DirectLOGIC PLCs
Enable Count Capture	0, 8, 16, 24	24.0, 24.8, 25.0, 25.8
Enable Timer Capture	0, 8, 16, 24	24.0, 24.8, 25.0, 25.8
Enable Pulse Catch	0, 8, 16, 24	24.0, 24.8, 25.0, 25.8
Reset	1, 9, 17, 25	24.1, 24.9, 25.1, 25.9

Input Function Status DWord Parameters

Input function offsets are listed in the order of Ch1/Fn1, Ch1/Fn2, Ch2/Fn1, Ch2/Fn2 and are in decimal format.

DWord Status CTRIO to CPU	DWord Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets from Output Start (octal)
DWord Parameter 1	0, 2, 4, 6	0, 4, 10, 14
DWord Parameter 2	1, 3, 5, 7	2, 6, 12, 16

Configured Function from CTRIO Workbench	Parameter 1 Contents DWORD	Parameter 2 Contents DWORD
Non-scaled Counter	Raw Input Value	Not Used
Scaled Counter	Scaled Value (pos. or rate)	Raw Value
Non-scaled Counter with Capture	Raw Value	Captured Value
Scaled Counter with Capture	Scaled Value (pos. or rate)	Captured Value
Non-scaled Timer	Previous Time (us)	In Progress Time (us)
Scaled Timer	Scaled Interval (rate)	In Progress Time (us)
Pulse Catch	Not Used	Not Used

Example Input Control/Status Bits and Parameter Register Addresses

The following tables provide example addresses based on V2000 selected for the base input address and V2030 selected for the base output address. The Input Functions discussed on the following pages use these example addresses.

Status Registers: Example using V2000 as base input address for Input Channel 1 (Status bits and DWords received from CTRIO to CPU)

Name	PLC Example 1: Bit-of-Word (see note 2) D2-250-1/260, D4-450	PLC Example 2: Control Relay (see note 1) D2-240	Value
Counter Capture Complete Bit	V2020.0	C160	ON when Capture is complete
Timer Capture Starting	V2020.0	C160	On when Timer Capture begins
Timer Capture Complete (Timing) OR At Reset Value (Counting)	V2020.1	C161	ON when Timer Capture complete
Timer "Timed Out" Bit	V2020.2	C162	On when specified Timer "Time Out" period is exceeded
Pulse Catch Output Pulse State	V2020.0	C160	ON for the specified pulse time if input pulse qualifies as a valid pulse
Pulse Catch Starting	V2020.1	C161	ON when pulse edge occurs
Parameter 1	V2001-V2000	V2001-V2000	Decimal
Parameter 2	V2003-V2002	V2003-V2002	Decimal


Control Registers: Example using V2030 as base output address for Input Channel 1 (Control bits sent from CPU to CTRIO)

Name	PLC Example 1: Bit-of-Word (see note 2), D2-250-1/260, D4-450	PLC Example 2: Control Relay (see note 1), D2-240 CPU	# Format
Enable Counter Capture	V2054.0	C260	Bit
Enable Timer Capture	V2054.0	C260	Bit
Enable Pulse Catch	V2054.0	C260	Bit
Reset	V2054.1	C261	Bit

Memory Mapping Example for D2-240 CPU

Note 1:

The D2-240 CPU does not support bit-of-word addressing. The status and control bits must be mapped to control relay words. An example of mapping code is shown below.



Note 2:

For example, *DirectSoft32* uses B2020.1 in the ladder code to indicate that you are addressing the second bit of V-memory register 2020. The “B” prefix indicates bit-of-word addressing.

Input Functions

Counter & Quadrature Counter

Parameters 1 and 2 are explained on page 6-16 and will be mapped to V2000 - V2003 in this example. If input D is configured for count Capture, the Enable Count Capture bit must be ON in order for input D to be able to snapshot the current count. The Count Capture Complete bit is used to indicate the acquisition has occurred. The program will need to turn OFF the Enable Capture and confirm the Capture Complete bit resets before attempting the next count capture. The Reset bit will reset raw and scaled values to the specified reset value. The last captured value, if applicable, will remain.

Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLC Status Inputs Base Addr = V2000 (Control Relay) D2-240	Description
Parameter 1		V2001-V2000		V2001-V2000	refer to table on page 6-16
Parameter 2		V2003-V2002		V2003-V2002	refer to table on page 6-16
Counter Capture Complete		V2020.0		C160	On when Count Capture is complete (Available only when input D is configured for Capture input)
Enable Count Capture	V2054.0		C260		Turn ON to Capture Count (Available only when input D is configured for Capture input)
Reset	V2054.1		C261		Turn ON to Reset Counter Value to Reset Value
At Reset Value		V2020.1		C161	On when Counter is at Reset Value

Edge Timer and Dual Edge Timer

Parameters 1 and 2 are explained on page 6-16 and will be mapped to V2000 - V2003 in this example.

Standard Timers:

When the Enable Timer Capture bit is ON and the configured input edge occurs, the CTRIO will begin timing. The Timer Capture Starting bit will be ON while the timing is in progress and will turn OFF when the next configured input edge occurs and the Timer Capture Complete bit turns ON. The program will need to turn off the Enable Timer Capture bit, and confirm the Timer Capture Starting and Timer Capture Complete bits reset before attempting the next time capture cycle. Turning OFF the Enable Timer Capture bit resets the timers register values to zero.

Free Run Timers:

If the Free Run Timer option was configured, the Enable Timer Capture bit is not available. When the configured input edge occurs, the CTRIO will begin timing. The Timer Capture Starting bit will be ON while the timing is in progress and will turn OFF when the next configured input edge occurs. When this edge occurs, the Timer “in progress time” register resets to zero. The “previous time” register will always retain the most recent captured time value.

Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLCStatus Inputs Base Addr = V2000 (Control Relay) D2-240	Description
Parameter 1		V2001-V2000		V2001-V2000	Previous Time
Parameter 2		V2003-V2002		V2003-V2002	In Progress Time
Timer Capture Starting		V2020.0		C160	On when Time Capture is in progress
Enable Timer Capture	V2054.0		C260		Turn ON to Enable Timer Capture Function (Not available when Free Run Timer option is selected)
Timer Capture Complete		V2020.1		C161	On when Timing is complete
Timer Timeout Bit		V2020.2		C162	

Edge and Dual Edge Timer Timeout Function

The Timer Timeout Function is available for use with standard and Free Run Timers. It is primarily used in Free Run timing of recurring events (rate, velocity calculations, etc.). The specified Timeout Period is in effect once the timer is enabled until receiving the first configured input edge. Then it is in effect until receiving the next edge of the timing input to complete the timing cycle.

Standard Timers:

Once the timer is enabled, the Timeout Bit is set if the time that it takes the CTRIO to see the configured input edge exceeds the specified Timeout Period. The program will need to turn off the Enable Timer Capture bit, and confirm the Timer Capture Complete bit and Timeout bit resets before attempting the next time capture cycle.

Once timing has been initiated, if the time before the CTRIO sees the next configured edge exceeds the specified Timeout Period, the Timeout bit is set. The Timer register values are reset to zero. The program will need to turn off the Enable Timer Capture bit, and confirm the Timer Capture Starting bit, Timer Capture Complete bit and the Timeout bit reset before attempting the next time capture cycle.

Free Run Timers:

The Timeout Bit is set if the time that it takes the CTRIO to see the configured input edge exceeds the specified Timeout Period. The Timeout bit resets when the next timing cycle begins. The “Previous Time” register value is reset to zero.

Once timing has been initiated, if the time before the CTRIO sees the next configured edge exceeds the specified Timeout Period, the Timeout bit is set. The Timer register values are reset to zero. The Timeout bit resets when the next timing cycle begins.

Pulse Catch Input Function

When the Enable Pulse Catch bit is ON and the configured input edge occurs, the CTRIO will begin timing and the Pulse Catch Starting bit will turn ON. If the input signal remains active for the specified qualification period, the Pulse Catch Output Pulse State bit will turn ON for the configured duration. If a discrete output is assigned to follow the pulse state, it will also turn ON for the configured duration. Unlike the Count or Time capture, the Pulse Catch function is automatically reset as long as the Enable Pulse Catch bit remains ON.

Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLCStatus Inputs Base Addr = V2000 (Control Relay) D2-240	Description
Pulse Catch Starting		V2020.0		C160	On when Pulse Catch is in progress
Enable Pulse Catch	V2054.0		C260		Turn ON to Enable Pulse Catch Function
Pulse Catch Output Pulse State		V2020.1		C161	ON for the Pulse Output Width duration specified in Configure I/O



The CTRIO will not recognize any input pulses while the Output Pulse is active. Take this into consideration when configuring the Pulse Output Width time.

Runtime Changes to CTRIO Configured Preset Tables

Presets and preset tables can be set up entirely within CTRIO Workbench so that no program control is necessary to assign discrete Preset Tables to CTRIO Input Functions.

You can make runtime edits to presets / preset tables from your control program. To make a runtime change, a series of commands must be executed which will pass new values to a preset table or call a different preconfigured table.

Command Codes are passed to the CTRIO module to effect the required edit. Each Command Code has its own syntax, and all Command Codes must be presented in a particular sequence:

The command code and associated parameters must be loaded into the appropriate memory locations.

A Process Command instruction must be passed to the CTRIO module.

A Command Complete signal must be received and the Command Error bit must stay at zero.

Finally, the Enable Output instruction must be passed to the CTRIO module.

Some changes require a combination of Command Codes so those changes must follow the steps above for each Command Code processed.

(Output Control and Status Offsets are listed in order of Output 0 - Output 3)

Control Bit (transfers from CPU to CTRIO)	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets DirectLOGIC PLCs
Enable Output	32, 40, 48, 56	26.0, 26.8, 27.0, 27.8
Process Command	39, 47, 55, 63	26.7, 26.15, 27.7, 27.15

Status Bit (transfers from CTRIO to CPU)	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets DirectLOGIC PLCs
Command Error	38, 46, 54, 62	22.6, 22.14, 23.6, 23.14
Command Complete	39, 47, 55, 63	22.7, 22.15, 23.7, 23.15

In order to process a command, first the program must load the Command and Required Word and DWord Parameters. Then the program should drive the Process Command bit to a 1 and look for the CTRIO to acknowledge the command with the Command Complete bit. Finally the program should remove the Process Command bit and set the Enable Output bit when appropriate. If the Command Error bit is received, the CTRIO was unable to process the command due to an illegal value in either the Command Code or Parameter fields.

Word Control CPU to CTRIO	Word Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets from Output Start (octal)
Command Code	0, 6	10, 16
Word Parameter 1	1, 7	11, 17
Word Parameter 2	2, 8	12, 20

DWord Control CPU to CTRIO	DWord Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets from Output Start (octal)
DWord Parameter 3	0, 2	0, 4

Runtime Changes Cont'd

Command DirectLOGIC n+10	Code Hex/BCD	Parameter 1 (Word) DirectLOGIC n+11	Parameter 2 (Word) DirectLOGIC n+12 (decimal)	Parameter 3 (DWord) DirectLOGIC n+0/n+1 (decimal)
Load Table from RAM	10	File Number (decimal)	-	-
Clear RAM Table ⁶	11	-	-	-
Initialize RAM Table	12	Entry Type (decimal)	Pulse Time ¹	Preset Count/Time ⁴
Add Table Entry ⁶	13	Entry Type (decimal)	Pulse Time ¹	Preset Count/Time ⁴
Edit Table Entry ⁶	File & ² 14	Entry Num. & ² Entry Type ³ (Hex/BCD)	Pulse Time ¹	Preset Count/Time ⁴
Write RAM to ROM ⁶	99 ⁵	-	-	-
Edit and Reload ⁶	File & ² 15	Entry Num. & ² Entry Type ³ (Hex/BCD)	Pulse Time ¹	Preset Count/Time ⁴
Initialize Table on Reset ⁶	16	Entry Type (decimal)	Pulse Time ¹	Preset Count/Time ⁴
Run to Position ⁶	22	-	-	Target Position
Edit Level Response ⁶	30	Level Behavior (decimal)	Deadband	Level Rate Setting

¹ If appropriate for Entry Type (in ms).

² Field entries separated by an "&" are to be loaded in the high byte and low byte of that word. See example on page 6-7.

³ Entry types are defined below.

⁴ Follows format of Input DWord Parameter 1.

⁵ Flash ROM is rated for 100,000 writes.

⁶ Counter/Quad Counter Reset must be ON to perform the Edit.

Entry Number for Edit Table Entry Commands

The Entry Number refers to the position of the preset in the table sequence. The first preset is Entry Number "0," the second preset is "1," and so forth.

Entry Type for Edit Table Entry Commands

The Entry Type is defined according to the table below.

Entry Type	Code	Notes
Write Output ON (Set)	0	-
Write Output OFF (Reset)	1	-
Pulse Output ON	2	-
Pulse Output OFF	3	-
Toggle Output	4	-
Reset Function	5	Edits preset that resets count

Discrete Outputs Driven from a Scaled level (Edit Level Response: Command Code 30)

If a Counter or Timer function is scaled to produce a rate, alarm level settings can be used to trigger discrete outputs at values predetermined by the user. The alarm levels can be set within CTRIO Workbench or from the user's control program.

Additionally, a deadband percentage (in tenths of a percent) can be set to prevent the output from changing too frequently near the Rate Level threshold.

“ON when greater” condition example:

Consider a Discrete Output set to turn ON when a level gets to 100 with a 10% deadband. The output will turn ON when the level gets to 100. If the level drops, the output will stay on until the level drops below 90, where it will turn OFF.

“OFF when less” condition example:

Consider a Discrete Output set to turn “OFF when less” at 100. When the level gets to 100, the output turns OFF. If the level rises again, the output will stay OFF until the level gets to 110, where it will turn ON.

Edit the behavior of a Discrete Output triggered by a Rate Level by using the “Edit Level Response Command” (Command Code 30Hex).

The Level Behavior setting for Parameter 1 is given in the table below:


Level Behavior for Discrete Output	Parameter 1 Contents
ON when greater than Level Rate setting	0000 Hex
ON when less than Level Rate setting	0080 Hex
OFF when greater than Level Rate setting	0001 Hex
OFF when less than Level Rate setting	0081 Hex

The Deadband is written to Parameter 2 as a x10 integer (one implied decimal position). To achieve a 10.0% deadband, the control program needs to write 100 decimal (64 Hex) to Parameter 2.

The Level Rate setting is written to Parameter 3 in the same format as Input Parameter 1 of the CTRIO Function to which this Discrete Output has been assigned.

Load Preset Table Flowchart

The flowchart below provides the logical sequence necessary to load and execute a discrete output preset table.



Pulse Output Status/Control Bits and Command Codes

Output Status Bit Definitions (Pulse Output)

Pulse output control Offsets are listed in the order of Outputs 0/1, 2/3.

Status Bit CTRIO to CPU	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V memory Offsets from Input Start (octal)
Output Enabled	32, 48	22.0, 23.0
Position Loaded	33, 49	22.1, 23.1
Output Suspended	34, 50	22.2, 23.2
Output Active	36, 52	22.4, 23.4
Output Stalled	37, 53	22.5, 23.5
Command Error	38, 54	22.6, 23.6
Command Complete	39, 55	22.7, 23.7

Output Control Bit Definitions (Pulse Output)

Pulse output control Offsets are listed in the order of Outputs 0/1, 2/3.

Control Bit CPU to CTRIO	Bit Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V memory Offsets from Output Start (octal)	Read as:
Enable Output	32, 48	26.0, 27.0	Level
Go to Position	33, 49	26.1, 27.1	Rising Edge
Suspend Output	34, 50	26.2, 27.2	Level
Direction	36, 52	26.4, 27.4	Level
Process Command	39, 55	26.7, 27.7	Rising Edge

Output Control (D)Words (Pulse Output)

Pulse output control Offsets are listed in the order of Outputs 0/1, 2/3.

Word Control CPU to CTRIO	Word Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets from Output Start (octal)
Command Code	0, 6	10, 16
Word Parameter 1	1, 7	11, 17
Word Parameter 2	2, 8	12, 20

DWord Control CPU to CTRIO	Word Offsets: WinPLC, EBC, PBC, DEVNETS, MODBUS	V-memory Offsets from Output Start (octal)
DWord Parameter 3	0, 2	0, 4

Command Code and Parameter Definitions

Command	Code (Hex/BCD)	Word Parameter 1 (decimal)	Word Parameter 2	DWord Parameter 3
Load Table from ROM	10	Trapezoid or S-curve Symmetrical S-Curve Home Search File Number	-	-
Load Table from ROM	10	Dynamic Positioning File Number	-	Target Position (decimal)
Load Table from ROM	10	Dynamic Velocity File Number	-	Target Velocity (decimal)
Velocity Mode	20	Run Frequency (20Hz - 25KHz)	Duty Cycle (0 to 99)* (decimal)	Number of Pulses (BCD/Hex)
Run to Limit Mode	21	Run Frequency (20Hz - 25KHz)	Edge & Duty Cycle (0 to 99)* (Hex/BCD)	-
Run to Position Mode	22	Run Frequency (20Hz - 25KHz)	Compare Function & Duty Cycle (0 to 99)* (Hex/BCD)	Desired Input Function Value (decimal)

* A value of 0 will generate a duty cycle of 50%

Fields above separated by an “&” indicate a code with different definitions for each byte (high byte and low byte). For example, to enter the Pulse Output to Limit command, set the high byte of the Word Parameter 2 to the edge you wish to terminate the output pulses (see definition following), and set the low byte to the desired duty cycle.

In order to process a command, first the program must load the Command Code and required DWord, Word, and bit parameters. Then the program should drive the Process Command bit to a 1 and look for the CTRIO to acknowledge the command with the Command Complete bit. Finally, the program should remove the Process Command bit and set the Enable Output bit when appropriate. If the Command Error bit is received, the CTRIO was unable to process the command due to an illegal value in either the Command Code or parameter files.

DWord and Word values for pulse outputs are unsigned integers.

**Status Bits: Example using V2000 as base input address For Output Channel 1
(Status bits received from CTRIO to CPU)**

Name	PLC Example 1: Bit-of-Word (see note 2) D2-250-1/260, D4-450	PLC Example 2: Control Relay (see note 1) D2-240	Value
Output Enabled	V2022.0	C120	ON when Enable Output is ON
Position Loaded	V2022.1	C121	Used for Dynamic Positioning
Output Suspended	V2022.2	C122	ON when Output pulse is suspended
Output Active	V2022.4	C124	ON when Output is Pulsing
Output Stalled	V2022.5	C125	CTRIO Output Fault (should never be ON)
Command Error	V2022.6	C126	ON if Command or Parameters are invalid
Command Complete	V2022.7	C127	ON if Module Receives Process Command


**Control Bits/Registers: Example using V2030 as base output address for Output
Channel 1 (Control DWords, Words, and bits sent from CPU to CTRIO)**

Name	PLC Example 1: Bit-of-Word (see note 2), D2-250-1/260, D4-450	PLC Example 2: Control Relay (see note 1), D2-240 CPU
Command Code	V2040	V2040
Parameter 1	V2041	V2041
Parameter 2	V2042	V2042
Parameter 3	V2031 - V2030	V2031 - V2030
Enable Output	V2056.0	C220
Go to Position	V2056.1	C221
Suspend Output	V2056.2	C222
Direction	V2056.4	C224
Process Command	V2056.7	C227

Memory Mapping Example for D2-240 CPU

Note 1:

The D2-240 CPU does not support bit-of-word addressing. The status and control bits must be mapped to control relay words. An example of mapping code is shown below.



Note 2:

For example, *DirectSOFT32* uses B2022.2 in the ladder code to indicate that you are addressing the third bit of V-memory register 2022. The “B” prefix indicates bit-of-word addressing.

Pulse Output Profiles

Loading a pre-defined Pulse Profile is the easiest method for pulse output motion control (Command Code = 0010 Hex/BCD). For the Trapezoid, S-Curve, Symmetrical S-Curve and Home Search profiles, all of the required characteristics of acceleration, run frequency, and total pulse count, etc. are entered in the CTRIO Workbench Pulse Profile entry window. For Dynamic Positioning and Dynamic Velocity profiles, the target position and target velocity are stored in a memory location in the controller. All other profile characteristics are entered in the CTRIO Workbench Pulse Profile entry window.

For Velocity Mode (Command Code = 0020 Hex/BCD), Run to Limit Mode (Command Code = 21 Hex/BCD) and Run to Position Mode (Command Code = 22 Hex/BCD) all profile parameters are stored in the controller's memory registers. No CTRIO Workbench Pulse Profile is required.

In order to process a command, first the program must load the Command Code and required DWord, Word, and bit parameters. Then the program should drive the Process Command bit to a 1 and look for the CTRIO to acknowledge the command with the Command Complete bit. Finally, the program should remove the Process Command bit and set the Enable Output bit when appropriate. If the Command Error bit is received, the CTRIO was unable to process the command due to an illegal value in either the Command Code or parameter files.

On the pages that follow, Pulse Profile and System Functions flowcharts are provided to give an overview of the steps needed to execute a pulse output profile or a SystemFunctions command. *Direct*LOGIC PLC addressing tables are also provided with CTRIO I/O data mapped in the word and CR bit areas of CPU memory shown on page 6-29.

Trapezoid, S-Curve, Symmetrical S-Curve, Home Search Profiles

For predefined Trapezoid, S-Curve, Symmetrical S-Curve and Home Search profiles, the program needs to prepare the Load Table command by selecting Command Code = 0010 Hex/BCD and setting Word Parameter 1 to the File number of the profile (example: File 1 Trapezoid 1). Then the program can set the Process Command bit and watch for the Command Complete bit. Then the program should clear the Process Command bit and set the Direction bit (if necessary) and finally the Enable Output bit to start the output pulses. Clearing the Enable Output bit will always suspend pulsing and reset any profile in progress to its beginning. Once complete, the profile remains loaded and can be restarted by clearing the Enable Output, changing the direction bit (if desired), and again setting the Enable Output. The flowchart on the next page provides the logical sequence necessary to execute a Trapezoidal, S-Curve, Symmetrical S-Curve or Home Search pulse profile.

For the Home Search routine, a CTRIO input must be assigned to Limit by the CTRIO Workbench Configure I/O dialog.


See Chapter 8 for a *Direct*LOGIC programming example that loads and runs a pulse profile using the bit/(D)word addressing in the table on the page 6-34.



For a Home Search Profile: if you are at the home position and the Home Search profile is initiated, there will not be any pulse outputs.

Trapezoid, S-Curve, Symmetrical S-Curve and Home Search Flowchart

The flowchart below provides the logical sequence necessary to execute a Trapezoid, S-Curve, Symmetrical S-Curve or Home Search pulse profile.



Running a Trapezoid, S-Curve, Symmetrical S-Curve Profile or Home Search Profile on CTRIO Y0 & Y1

Steps	Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLC Status Inputs Base Addr = V2000 (Control Relay) D2-240	Action
1	Command Code	V2040		V2040		Set to 10 (Load Stored Profile)
2	Parameter 1	V2041		V2041		File # of stored profile, determined by user
3	Process Command	V2056.7		C227		Turn ON until Command Complete status bit is returned (see step 4)
4	Command Complete Status		V2022.7		C127	When ON, Profile is now loaded, clear Process Command bit (step 3)
5	Command Error		V2022.6		C126	ON if Command or Parameters are invalid
6	Set Direction	V2056.4		C224		Set ON or OFF for Direction of Rotation
7	Enable Output	V2056.0		C220		Turn ON to start pulses
8	Output Enable Status		V2022.0		C120	When ON, module is confirming Enable Output
9	Output Active Status		V2022.4		C124	When ON, module is pulsing, OFF with Enable Status ON = profile has completed
10	Disable Output	V2056.0		C220		Turn OFF when pulse status is OFF and Enable Status is ON
11	Suspend Output	V2056.2		C222		Turn ON to "pause" output pulses without resetting pulse count
12	Output Suspended		V2022.2		C122	ON when out pulse train has been suspended

Dynamic Positioning

For Dynamic Positioning, only the motion limits of Min Frequency, Max Frequency, and Acceleration rate come from the CTRIO Workbench Profile. After loading a Dynamic Position Profile, setting the Enable Output causes the CTRIO module to assume a position of 0 pulses. The program should write the next target position in DWord Parameter 3, and set the Go to Position bit. This will cause the CTRIO to set both the Pulses Active and the New Position Loaded bit and begin to output pulses. The number of pulses and direction are determined by the CTRIO based on the difference between the current location and the specified target location. The flowchart on the following page provides the logical sequence necessary to execute a Dynamic Positioning pulse profile.


The program can monitor the state of the Pulses Active bit and the New Position Loaded bit to determine when the new position has been attained. The New Position Loaded status bit will always follow the state of the Load/Seek New Position control bit. This status bit should be used to signal the program that the CTRIO has received the new state of the control bit.

Position Loaded Status Bit V40622.1 or C441	Pulses Active Status Bit V40622.0 or c440	CTRIO Dynamic Position Pulse Output State
0	0	Idle
1	1	Go To Position Acknowledged, Pulsing
0	1	Still Pulsing, Go To Position Control Bit is OFF
1	0	Go To Position Acknowledged, Position Attained

You do not have to wait on the CTRIO to complete a move that is in progress before loading the next target location. After the GoTo Position is acknowledged, the program can load the next position into the DWord Parameter 3. When Pulses Active Status goes to 0, then setting the GoTo Position control bit will again start the output toward the new position. The CTRIO moves to the new position relative to its previous position as long as the Enable Output control bit remains set. Clearing the Enable Output bit will disable output pulsing and reset the current position to 0.


See Chapter 8 for a *Direct*LOGIC programming example that executes a Dynamic Positioning pulse profile using the bit/(D)word addressing in the table on page 6-37.

The sign of the value in the Target Position register (Parameter 3) determines the direction of the pulse train output. In the *Direct*LOGIC programming example to the right, BCD 5000 is converted to decimal -5000 when C0 is turned ON. You could load (LD) a V memory location instead of using a constant as shown in the example.




Dynamic Positioning Flowchart

The flowchart below provides the logical sequence necessary to execute a Dynamic Positioning pulse profile.



Turning on Output Enable sets the 'zero point' for the CTRIO, that is, the current position value is set to 0.



The direction will be determined automatically by the CTRIO.

Once the current position is loaded, The CTRIO will begin to send output pulses. You can suspend the pulse output at any time by using the Suspend Output bit. Using Suspend Output will NOT reset the 'zero-point'.

If you have more position values, you can load them as soon as the Position Loaded bit comes ON. You don't have to wait for the currently loaded position to be reached.

Dynamic Positioning using the CTRIO Y0 and Y1

Steps	Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLC Status Inputs Base Addr = V2000 (Control Relay) D2-240	Action
1	Command Code	V2040		V2040		Set to 10 (Load Stored Profile)
2	Parameter 1	V2041		V2041		File # of desired Dynamic Positioning Profile
3	Process Command	V2056.7		C227		Turn ON until Command Complete status bit is returned (see step 4)
4	Command Complete Status		V2022.7		C127	When ON, Profile is now loaded, clear Process Command bit (step 3)
5	Command Error		V2022.6		C126	ON if Command or Parameters are invalid
6	Enable Output	V2056.0		C220		Turn ON to assume 0 position, Turn OFF to disable pulses and zero position
7	Output Enable Status		V2022.0		C127	When ON, pulses are now enabled and last position is retained
8	Parameter 3	V2031 / V2030		V2031 / V2030		Target position: User defined (DWord)
9	Go To Position	V2056.1		C221		Starts pulses with direction to obtain the new position relative to previous position.
10	Position Loaded Status		V2022.1		C121	When ON, Go To position is acknowledged
11	Output Active Status		V2022.4		C124	When ON, module is pulsing, OFF with Position Loaded status ON = new position move has completed
12	Go To Position	V2056.1		C221		Turn OFF to be ready to load a new position
13	Suspend Output	V2056.2		C222		Turn ON to "pause" output pulses without resetting pulse count
14	Output Suspend		V2022.2		C122	ON when out pulse train has been suspended

To seek the next position, repeat steps 7-10.

Dynamic Velocity

For Dynamic Velocity, the motion limits of clockwise acceleration and deceleration, and counter clockwise acceleration and deceleration come from the CTRIO Workbench Profile.

The target velocity is stored in a register in the CPU/controller.


The program needs to prepare the Load Table command by selecting Command Code = 0010 Hex/BCD, set Word Parameter 1 to the File number of the profile (example: File 3 Dynamic Velocity 1) and set Word Parameter 3 to the desired target velocity. Then the program can set the Process Command bit and watch for the Command Complete bit. Then the program should clear the Process Command bit. Set the Enable Output bit to start the output pulses. The velocity can be changed “on the fly” by entering a different value into the target velocity register. The velocity will ramp up/down to the new target velocity at the specified accel/deccl rates. Clearing the Enable Output bit will always suspend pulsing.

See Chapter 8 for a *Direct*LOGIC programming example that executes a Dynamic Velocity pulse profile using the bit/(D)word addressing in the table below.

Dynamic Velocity using the CTRIO Y0 and Y1


Steps	Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLC Status Inputs Base Addr = V2000 (Control Relay) D2-240	Action
1	Command Code	V2040		V2040		Set to 10 (Load Stored Profile)
2	Parameter 1	V2041		V2041		File # containing cw accel/deccl and ccw accel/deccl
3	Process Command	V2056.7		C227		Turn ON until Command Complete status bit is returned
4	Command Complete Status		V2022.7		C127	When ON, Profile is now loaded, clear Process Command bit
5	Command Error		V2022.6		C126	ON if Command or Parameters are invalid
6	Enable Output	V2056.0		C220		Turn ON to ramp to target velocity, Turn OFF to disable pulses.
7	Parameter 3	V2031 / V2030		V2031 / V2030		Target velocity: User defined (DWord)
8	Output Active Status		V2022.4		C124	When ON, module is pulsing
9	Suspend Output	V2056.2		C222		Turn ON to “pause” output pulses without resetting pulse count
10	Output Suspended		V2022.2		C122	ON when out pulse train has been suspended

The sign of the value in the Target Velocity register 1 (Parameter 3) determines the direction of the pulse train output. In the *Direct*LOGIC programming example to the right, BCD 5000 is converted to decimal -5000 when C0 is turned ON. You could load (LD) a V memory location instead of using a constant as shown in the example.



Dynamic Velocity Mode Flowchart

The flowchart below provides the logical sequence necessary to execute a Dynamic Velocity pulse profile.



Velocity Mode



Velocity Mode controls the pulse outputs directly from the CPU/controller program. No CTRIO Workbench Pulse Profile is required for this mode.

Velocity Mode command (Command = 0020 Hex/BCD) allows a specified number of pulse output counts or the number of Pulses can be set to “FFFFFFF” in Hex for unlimited pulse counts. Leaving the Duty Cycle set to 0 achieves the default (50%), otherwise it can be set in 1% increments by writing this value from 1 to 99 decimal. After this command is processed, the Run Frequency and Duty Cycle fields can be adjusted by direct access. In order to change directions from Pulse Output in “Velocity” mode, the Enable Output bit must first be cleared (which stops the Pulse Outputs). Then after the new direction bit is written, the Enable Output bit can be set to resume pulsing. The flowchart on the following page provides the logical sequence necessary to execute a Velocity Mode pulse profile.

See Chapter 8 for a *DirectLOGIC* programming example that executes a Velocity Mode pulse profile using the bit/(D)word addressing in the table below.


Velocity Mode control on CTRIO Y0 & Y1

Steps	Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLC Status Inputs Base Addr = V2000 (Control Relay) D2-240	Action
1	Command Code	V2040		V2040		Set to 20 Hex (Pulse at Velocity)
2	Parameter 1	V2041		V2041		Set initial run frequency (20Hz-25000Hz) decimal
3	Parameter 2	V2042		V2042		Duty cycle (1-99) (can leave 0 for 50%) decimal
4	Parameter 3	V2031 / V2030		V2031 / V2030		Number of pulses (DWord); set to FFFF FFFF for no limit, Hex
5	Set Direction	V2056.4		C224		Set ON or OFF for Direction of Rotation
6	Process Command	V2056.7		C227		Turn ON Command Complete status bit is returned (see step 4)
7	Command Status		V2022.7		C127	When ON, command has been accepted, clear Process Command bit (step 3)
8	Command Error		V2022.6		C126	ON if Command or Parameters are invalid
9	Enable Output	V2056.0		C220		Turn ON to start pulses
10	Disable Output	V2056.0		C220		Turn OFF to start pulses
11	Suspend Output	V2056.2		C222		Turn ON to “pause” output pulses without resetting pulse count
12	Output Suspended		V2022.2		C122	ON when out pulse train has been suspended

While Velocity Mode Control is running, Run Frequency (step 2) and Duty Cycle (step 3) may be actively changed simply by writing a new Parameter value. Since no accel/decel parameters are specified in this profile, the output change is a step response.

Velocity Mode Flowchart

The flowchart below provides the logical sequence necessary to execute a Velocity Mode pulse profile.



Run to Limit Mode



Run to Limit Mode controls the pulse outputs directly from the CPU/controller program. No CTRIO Workbench Pulse Profile is required for this mode.

The Run to Limit (Command = 0021Hex/BCD) can be used to seek limit positions or for Home Search routines. You may want to consider using the Home Search Pulse Profile(s) created using Workbench unless you need the CPU/controller to control the entire profile and parameters, etc. The CTRIO input must be assigned for Limit by the CTRIO Workbench utility.

Set Word Parameter 1 to the desired Frequency. Set Word Parameter 2 Low Byte to the Duty Cycle and the High Byte to the Edge to Seek as defined below. Leaving the Duty Cycle set to 0 achieves the default (50%), otherwise it can be set in 1% increments by writing this value from 1 to 99 Hex/BCD.

The flowchart on the following page provides the logical sequence necessary to execute a Run to Limit pulse profile.

See Chapter 8 for a *Direct*LOGIC programming example that executes a Run to Limit Mode pulse profile using the bit/(D)word addressing in the table on page 6-44.

Parameter 2


Word Parameter 2 defines three elements of the Run to Limit routine. Bits 13 and 12 determine which edge(s) to terminate Output Pulses and Bits 9 and 8 determine which CTRIO Input terminal to use for the limit. The low byte specifies the duty cycle.

Edge to Seek	Parameter 2 Bits 13 & 12	Parameter 2 Bits 9 & 8	Parameter 2 (Hex) (Duty cycle at 50%)
Rising Edge Ch1 C	00	00	0000
Falling Edge Ch1 C	01	00	1000
Both Edge Ch1 C	10	00	2000
Rising Edge Ch1 D	00	01	0100
Falling Edge Ch1 D	01	01	1100
Both Edge Ch1 D	10	01	2100
Rising Edge Ch2 C	00	10	0200
Falling Edge Ch2 C	01	10	1200
Both Edge Ch2 C	10	10	2200
Rising Edge Ch2 D	00	11	0300
Falling Edge Ch2 D	01	11	1300
Both Edge Ch2 D	10	11	2300

Edge(s)	Bits 15..12	CTRIO Input	Bits 11..8
Rising	0000, 0Hex	Ch 1 C	0000, 0Hex
Falling	0001, 1Hex	Ch 1 D	0001, 1Hex
Both	0010, 2Hex	Ch 2 C	0010, 2Hex
		Ch 2 D	0011, 3Hex

Run to Limit Mode Flowchart

The flowchart below provides the logical sequence necessary to execute a Run to Limit Mode pulse profile.



Run at Velocity on CTRIO Y0 & Y1 until Discrete Input Limit

Steps	Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLC Status Inputs Base Addr = V2000 (Control Relay) D2-240	Action
1	Command Code	V2040		V2040		Set to 21 Hex (Run to Limit Mode)
2	Parameter 1	V2041		V2041		Set initial run frequency (20Hz-25000Hz) decimal
3	Parameter 2	V2042		V2042		Select discrete input edge in high byte, low byte = duty cycle (1-99) Example: rising input 1D at Duty = 45%, set this parameter to 212D Hex
4	Set Direction	V2056.4		C224		Set ON or OFF for Direction of Rotation
5	Process Command	V2056.7		C227		Turn ON Command Complete status bit is returned (see step 4)
6	Command Status		V2022.7		C127	When ON, command has been accepted, clear Process Command bit (step 3)
7	Command Error		V2022.6		C126	ON if Command or Parameters are invalid
8	Enable Output	V2056.0		C220		Turn ON to start pulses
9	Output Active Status		V2022.4		C124	ON while pulsing, OFF when limit has stopped pulsing
10	Suspend Output	V2056.2		C222		Turn ON to "pause" output pulses without resetting pulse count
11	Output Suspended		V2022.2		C122	ON when out pulse train has been suspended

Run to Position Mode



Run to Position Mode controls the pulse outputs directly from the CPU/controller program. No CTRLIO Workbench Pulse Profile is required for this mode.

The Run to Position Mode command (Command = 0022Hex/BCD) allows Pulse Outputs that terminate when the specified Input Function Value position count is reached. Set Word Parameter 1 to the desired Frequency. Set Word Parameter 2 Low Byte to the Duty Cycle and the High Byte to the Compare Functions as defined below. Leaving the Duty Cycle set to 0 achieves the default (50%), otherwise it can be set in 1% increments by writing this value from 1 to 99 Hex/BCD.

Word Parameter 3 specifies the value that Input Function will compare against.

The flowchart on the following page provides the logical sequence necessary to execute a Run to Position pulse profile.

See Chapter 8 for a *Direct*LOGIC programming example that executes a Run to Position pulse profile using the bit/(D)word addressing in the table on page 6-47.

Parameter 2

Word Parameter 2 defines three elements of the Run to Position routine. Bit 12 determines if the specified position is “greater than or equal” or “less than” the current Input Function position value. Bits 9 and 8 determine which Input Function to use for the comparison. The low byte specifies the duty cycle.


Specified Position (Parameter 3) is:	Parameter 2 Bit 12	Parameter 2 Bits 9 & 8	Parameter 2 (Hex) (Duty cycle at 50%)
less than Ch1/Fn1	0	00	0000
greater than Ch1/Fn1	1	00	1000
less than Ch1/Fn2	0	01	0100
greater than Ch1/Fn2	1	01	1100
less than Ch2/Fn1	0	10	0200
greater than Ch2/Fn1	1	10	1200
less than Ch2/Fn2	0	11	0300
greater than Ch2/Fn2	1	11	1300

Comparison	Bits 15..12
Greater Than or Equal	0001, 1Hex
Less Than	0000, 0Hex

Input Function	Bits 11..8
Ch 1 Fn 1	0000, 0Hex
Ch 1 Fn 2	0001, 1Hex
Ch 2 Fn 1	0010, 2Hex
Ch 2 Fn 2	0011, 3Hex

Run to Position Mode Flowchart

The flowchart below provides the logical sequence necessary to execute a Run to Position Mode pulse profile.



Run at Velocity on CTRIO until Input Function Value Position

Steps	Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLC Status Inputs Base Addr = V2000 (Control Relay) D2-240	Action
1	Command Code	V2040		V2040		Set to 22 Hex (Pulse at velocity until Function Input Limit)
2	Parameter 1	V2041		V2041		Set initial run frequency (20Hz-25000Hz) decimal
3	Parameter 2	V2042		V2042		Bits 15-12: Comparison Bits 11-8: Input Function to use Low Byte:Duty cycle (1-99) (can leave 0 for 50%) Hex
4	Parameter 3	V2031 / V2030		V2031 / V2030		Specified position for Input Function DWord to compare against, decimal
5	Set Direction	V2056.4		C224		Set ON or OFF for Direction of Rotation
6	Process Command	V2056.7		C227		Turn ON Command Complete status bit is returned (see step 4)
7	Command Status		V2022.7		C127	When ON, command has been accepted, clear Process Command bit (step 3)
8	Command Error		V2022.6		C126	ON if Command or Parameters are invalid
9	Enable Output	V2056.0		C220		Turn ON to start pulses
10	Output Active Status		V2022.4		C124	ON while pulsing, OFF when position is reached
11	Suspend Output	V2056.2		C222		Turn ON to "pause" output pulses without resetting pulse count
12	Output Suspended		V2022.2		C122	ON when out pulse train has been suspended

System Functions

System Functions Commands are primarily used to read from and write to the CTRIO's internal registers. The flowcharts on the following pages provide *DirectLogic* and ThinknDo users the logical sequence necessary to read from and write to the CTRIO's internal registers.

The CTRIO's internal current count register can be read from or written to if the input is configured for a Counter or Quadrature Counter. Timer values are not accessible.


The CTRIO's internal current output pulse count can be read from or written to only if the pulse output is running Dynamic Velocity or Dynamic Positioning profiles.

See Chapter 8 for *DirectLOGIC* programming examples that use the RD and WT instructions to execute system function commands.

Steps	Name	PLC Control Outputs Base Addr = V2030 (Bit-of-Word)	PLC Status Inputs Base Addr = V2000 (Bit-of-Word)	PLC Control Outputs Base Addr = V2030 (Control Relay) D2-240	PLC Status Inputs Base Addr = V2000 (Control Relay) D2-240	Action
1	Command Code	User Specified to use with RD/WT Instruction		User Specified to use with RD/WT Instruction		1 Hex: Read All Registers 2 Hex: Write All Registers 4 Hex: Write One Register 5 Hex: Write Reset Value
2	System Command Error		V2024.6		C106	ON if Command or Parameters are invalid
3	System Command Complete		V2024.7		C107	When ON, command has been accepted, clear Process Command bit
6	Process Command	V2060.7		C207		Turn ON Command Complete status bit is returned

Note 1:

The D2-240 CPU does not support bit-of-word addressing. The status and control bits must be mapped to control relay words. An example of mapping code is shown below.



Note 2:


For example, *DirectSoft32* uses B2020.1 in the ladder code to indicate that you are addressing the second bit of V-memory register 2020. The “B” prefix indicates bit-of-word addressing.

Reading All CTRIO's Internal Registers Flowcharts


The flowcharts below provide the logical sequence necessary to Read the CTRIO's internal registers. Reading the CTRIO's internal registers is a two-step process.

- 1) Ask the CTRIO to transfer the internal register values to its shared RAM.
- 2) Transfer the values from the CTRIO's shared RAM to the controller's memory.

DirectLogic Read from CTRIO



ThinknDo Read from CTRIO




Writing to All CTRIO's Internal Registers Flowcharts


The flowcharts below provide the logical sequence necessary to Write to all of the CTRIO's internal registers. Writing to the CTRIO's internal registers is a two-step process.

- 1) Transfer the data values from the controller's memory to the CTRIO's shared RAM.
- 2) Ask the CTRIO to transfer these values from its shared RAM to its internal registers.

DirectLogic Write to CTRIO



ThinknDo Write to CTRIO




Writing to One CTRIO Internal Register Flowcharts


The flowcharts below provide the logical sequence necessary to Write to one of the CTRIO's internal registers. Writing to a CTRIO internal register is a two-step process.

- 1) Transfer the data value from the controller's memory to the CTRIO's shared RAM.
- 2) Ask the CTRIO to transfer this value from its shared RAM to its internal registers.

DirectLogic Write to CTRIO



ThinknDo Write to CTRIO



USING MONITOR I/O



In This Chapter...

Using the Monitor I/O Dialog	7-2
Monitor I/O Error Codes	7-7

Using the Monitor I/O Dialog




It is highly recommended to simulate your CTRIO Counter, Timer or Pulse Output Profile, etc. application using Monitor I/O before attempting to control the module from your controller program. Monitor I/O is extremely useful for debugging and the commissioning of a new system. Monitor I/O allows you to confirm proper configuration of the module, as well as field wiring and external device operation.

The Monitor I/O dialog is accessible from the main Workbench dialog when the module is in Run Mode.

On the main Workbench dialog, click the button labeled Monitor I/O.



After clicking on the Monitor I/O button, the dialog below will appear if you have mapped the I/O in the CTRIO to the controller. Here you have the ability to suspend CTRIO reads from the CPU/controller. Doing so will allow Monitor I/O to control the CTRIO without any control program intervention. With the output reads suspended, the Monitor I/O dialog allows you to simulate program control; for example, enabling a timer, resetting a counter, running a pulse profile or turning on an output configured for Raw mode, etc. When exiting Monitor I/O, you will be prompted to re-enable the controller output reads.




The Monitor I/O dialog is divided into three functional areas: I/O Status & Input Functions, Output Functions and System Functions. Just below the Windows title bar, you will see tabs to switch between the three Functions. The functions are described on the pages that follow.



I/O Status & Input Functions

I/O Status & Input Functions dialog includes all Input Function DWord Parameters (raw count/time, scaled count/time, etc.) and status bits passed from the CTRIO module to the CPU (Capture Starting, Complete bits, etc.). The control bits that would be passed from the CPU to the CTRIO are also included (Function enable bits, etc.).

The current status of each configured input and output is shown just below the Input Status and Output Status columns.




In the example above, the Current Count for Ch1/Fn1 Quad counter is 994. The Reset Count button can be used to reset the count to the configured Reset Value.

For Ch1/Fn2, the Edge Timer is captured at 38us. The Enable Capture bit must be on prior to when the configured edge input occurs.

Note that Output Status Out 0 and Out 3 are ON. Out 0 is configured for pulse output and Out 3 is configured for a Raw discrete output. These outputs can be controlled from the Output Functions window.

Output Functions

The Output Functions dialog includes all Output Function Word and DWord Parameters (file number, duty cycle, target position, etc.) and status bits passed from the CTRIO module to the CPU (Output Enabled, Command Complete, etc.). The control bits that would be passed from the CPU to the CTRIO are also included (Enable Output, Go to Position, Direction, etc.).



In the example above, Outputs 0 and 1 are configured for Pulse step and direction, Output 2 is configured to Preset mode assigned to Ch1/Fn1 (quad counter) and Output 3 is configured as Raw mode.

In the screen capture on the left, notice the pull down menu. The menus are context sensitive. They will change to display values that are appropriate to the CTRIO's configuration. Here you have access to all pulse profile commands. Command 0x10 will allow you to load any configured Pulse Profiles (Trapezoidal, S-Curve, Dynamic Positioning, etc.). In the screen capture on the right, you'll see we have selected Pulse Profile number 2 for this example.

To run a configured Pulse Profile, follow these steps:


- 1) select Command Code 10 (0x10)
 - 2) enter the desired Pulse Profile Number in the File Number field
 - 3) click the Process Command button and confirm the Command Complete bit is ON. If the Command Error is ON, an explanation of the error will appear on the dialog status line. Then turn the Process Command button OFF.
 - 4) select the Direction; leaving the Direction button OFF selects forward, clicking the button ON selects the reverse direction.
 - 5) click on Enable Output to run the Pulse Profile. The Output Enabled and Output Active indicators will turn ON. When the profile is complete, the Output Active indicator will turn OFF.
- Turning OFF the Enable Output during the profile run will terminate the pulse output. To run the profile again, turn OFF the Enable Output and then re-enable it.

In the screen capture on the right on the previous page, notice the drop down menu. Here you have access to all of the Preset Table Commands. The Load Table Command (0x10) will allow you to load any configured Preset Tables. In the screen capture on the left, you'll see we have selected Preset Table number 1 for this example. Remember that Output 2 is assigned to Input Function Ch1/Fn1, which is configured as a Quad Counter Input.

To load a configured Preset Table for Output 2 to use based on Ch1/Fn1's count, follow the steps below:

- 1) select Command Code 10 (0x10)
- 2) enter the desired Preset Table Number in the File Number field
- 3) click the Process Command button and confirm the Command Complete bit is ON. If the Command Error is ON, an explanation of the error will appear on the dialog status line. Then turn the Process Command button OFF.
- 4) click on the Enable Output to allow the output to operate based on the Preset Table and current status of Ch1/Fn1 quad counter input.

As the encoder's count on Ch1/Fn1 changes, the output 2 turns ON and OFF based on the entries in Preset Table number 1. Turning the Enable Output OFF while the Preset Table is being executed will disable the output.



Pulse Output Command Codes 0x20, 0x21 and 0x22

Velocity mode (0x20) is shown in the example above. Depending upon which command is selected, different parameter fields, status bits and control bits will apply. No matter which one is selected, be sure to fill in the parameter fields with valid entries (refer to chapter6), and then Process the Command.

System Functions

The Systems Functions dialog allows you read from or write to the current input count and the current output pulse count under the following conditions:


- The current input count can be read from or written to if the input is configured for a Counter or Quad Counter. Timer values are not accessible.
- The current output pulse count can be read from or written to only if the pulse output is running Dynamic Velocity or Dynamic Positioning profiles.

DirectLogic Users

The reading from and writing to the CTRIO internal registers is accomplished using the *DirectLOGIC* Read from Intelligent module (RD) and Write to Intelligent module (WT) instructions, respectively. See chapter 8 for Systems Functions ladder logic examples.

EBC, WinPLC, PBC, DEVNETS, MODBUS Users


The Systems Functions dialog is available for use when connected to these interface devices, however, there is currently no way for the user control program to read from or write to the CTRIO's internal registers.



Monitor I/O Error Codes

The appropriate error code listed below will be displayed on the Monitor I/O Status Bar when an error occurs.

Error Code	Description
0	No error
100	Specified command code is unknown or unsupported
101	File number not found in file system
102	File type is incorrect for specified output function
103	Profile type is unknown
104	Specified input is not configured as a limit on this output
105	Specified limit input edge is out of range
106	Specified input function is unconfigured or invalid
107	Specified input function number is out of range
108	Specified preset function is invalid
109	Preset table is full
110	Specified table entry number is out of range
111	Specified register number is out of range
112	Specified register is in unconfigured input or output



Status bar

DIRECTLOGIC

PROGRAMMING EXAMPLES



In This Chapter...

Programming Examples Overview	8-2
Load and Run a Pulse Profile	8-3
Dynamic Positioning Profile	8-4
Dynamic Velocity Profile	8-5
Velocity Mode	8-6
Run to Position Mode	8-7
Dynamic Positioning Profile	8-8
System Functions Examples Overview	8-9
Simulating Retentive Counter	8-10
Reading CTRIO Internal Registers	8-11

Programming Examples Overview



The programming examples on the following pages are provided “as is” without a guarantee of any kind. This Chapter is provided by our technical support group to assist others. We do not guarantee the examples are suitable for a particular application, nor do we assume any responsibility for them in your application. Chapter 6 “Program Control” contains flowcharts that provide detailed steps needed to execute a pulse profile or System Functions command.

The *Direct*LOGIC programming examples provided on the following pages are simple examples that are intended to assist you in the basics of loading and running various output pulse profiles. The examples are complete enough to load a profile, process the command and load the Parameter registers necessary to execute the profile. Two System Functions examples are also provided.

Load and Run a Pulse Profile example:

You will need to have a Trapezoid, S-Curve, Symmetrical S-Curve or Home Search profile configured using the Configure I/O dialog. You will need to have the appropriate Pulse Profile Table File Number (decimal) stored in V3000 for this example. You must turn C0 on to load and run the pulse profile. C2 controls the pulse output direction.

Dynamic Positioning Profile example:

You will need to have a Dynamic Positioning profile configured as Table File Number 1 using the Configure I/O dialog. You will need to have the appropriate Target Pulse Count Position (signed decimal) stored in V3000 for this example. You must turn C0 on to initialize the settings. Then turn C2 on to Go to Position.

Dynamic Velocity Profile example:

You will need to have a Dynamic Velocity profile configured as Table File Number 1 using the Configure I/O dialog. You will need to have the appropriate Target Velocity (signed decimal) stored in V3000 for this example. You must turn C0 on to initialize the settings and enable the output.

Velocity Mode, Run to Limit Mode and Run to Position Mode examples:

No CTRIO Pulse Profile Tables are necessary to execute these profiles, but the Outputs need to be configured for Step/Direction or CW/CCW using the Configure I/O dialog. All parameters are stored in V-memory as shown in the examples. You must turn C0 on to initialize the settings and to run the pulse profile. C2 controls the pulse output direction.

Simulating Retentive Counter example:


This Systems Functions example uses the Write to Intelligent (WT) instruction to write the current count stored in the PLC's retentive memory to the CTRIO's current count register on a power cycle or a RUN-STOP-RUN PLC mode change. No permissive bits are required to be turned on in this example.

Reading CTRIO Internal Registers example:

This Systems Functions example uses the Write to Intelligent Module (WT) and Read from Intelligent Module (RD) instructions to read all of the CTRIO's internal registers every 900ms. You must turn C0 on to initialize the settings to perform the Read routine.


Load and Run a Pulse Profile

The following example program loads and executes a Pulse Profile that was created using CTRIO Workbench Pulse Profiles dialog . This example can be used for Trapezoid, S-Curve, Symmetrical S-Curve and Home Search profiles (Home Search requires that CTRIO inputs C and/or D are configured for Limit Out 0 and/or Limit Out 2). The Pulse Profile number is stored in V3000 for this example. Turning on C0 will load and run the pulse profile.




Dynamic Positioning

The following example program runs a Dynamic Positioning pulse profile. Turn on C0 to load the profile number and process the command. Turning on C2 will start the pulse output to position specified in Parameter 3. The sign of the value in the target pulse count register controls the pulse output direction. When a new position is specified, the CTRIO moves to the new position relative to its previous position as long as the Enable Output bit remains set. Clearing the Enable Output bit will disable output pulsing and reset the current position to 0.




Dynamic Velocity

The following example program executes a Dynamic Velocity pulse profile. Turn C0 on to load the profile number, process the command and enable the output. The Target Velocity needs to be specified in V3000. The velocity can be changed “on the fly” by entering a different value into V3000. The sign of the value in the target velocity register controls the pulse output direction. Clearing the Output Enable bit will always suspend pulsing.




Velocity Mode

The following example program loads and executes a Velocity Mode pulse profile. For Parameter 3, a specific number of pulse output counts can be specified or if set to “ffffff” Hex, the pulse output will remain ON at the specified Target Velocity until the output is disabled.




Run to Limit Mode

The following example program loads and executes a Run to Limit Mode pulse profile. Turn on C0 to run the profile. CTRIO input C or D must be assigned to Limit for this profile.



Run to Position Mode

The following example program loads and executes a Run to Position Mode pulse profile. Turn on C0 to run the pulse profile.



System Functions Examples Overview

The Systems Functions examples on the following pages use the *DirectLOGIC* Write to Intelligent Module (WT) and/or Read from Intelligent Module (RD) instructions to write to or read from the CTRIO's internal registers.

Reading From CTRIO Internal Memory

Reading the CTRIO's internal memory consists of several steps. Step one is using the WT instruction to send a Systems Function's command to the CTRIO telling it to put its internal register values into the CTRIO's "shared RAM". Step two is processing the request for the internal register values using the Process Command bit. Step three is using the RD instruction to read the values from the CTRIO's "shared RAM" memory into PLC V-memory.

Steps 1 and 2: WT instruction and Process Command

```

PLC V-memory ==> CTRIO's Shared RAM
CTRIO's Shared RAM ==> Process Command to internal processor
CTRIO's Shared RAM <== Internal data values

```

Step3: RD instruction

```

PLC V-memory <== CTRIO's Shared RAM

```

Writing to CTRIO Internal Memory

Writing to the CTRIO's internal registers is basically a two step process. Step one is using the WT instruction to send a System Function's command and the desired data values to the CTRIO's "Shared RAM". Step two is using the Process Command bit to tell the CTRIO to process the command and data values that are in the CTRIO's Shared RAM. This moves the data values from the Shared RAM into the CTRIO's internal registers.

Steps 1 and 2: WT instruction (command and data) and Process Command Bit:


```

PLC V-memory ==> CTRIO Shared RAM
CTRIO Shared RAM ==> Process Command to internal processor
CTRIO Shared RAM ==> internal data registers

```

Simulating Retentive Counter

The following Systems Functions example uses the Write to Intelligent (WT) instruction to write the current count stored in the PLC's retentive memory to the CTRIO's current count register on a power cycle or a RUN-STOP-RUN PLC mode change.



Reading CTRIO Internal Registers

The following Systems Functions example uses the Write to Intelligent Module (WT) and Read from Intelligent Module (RD) instructions to read all of the CTRIO's internal registers every 900ms and place the data starting at V2200.

